

### **Installation Instructions**

Thanks for purchasing your new Roofnest! Installation is straightforward in most cases and requires no special skills or tools.

## **Preliminary Information:**

You need to a minimum of two horizontal crossbars that are recommended to be at least 44" wide (48" wide for the Eagle).


The shape of the crossbar (aero, round, square) does not matter – the mounting hardware included with your tent will work for 95% of roof rack crossbars out there.

Your crossbars must be no more than 4 inches across or 3 inches thick - if your crossbars are bigger than this you will need to purchase separate mounting hardware - email us at **info@roofnest.com** and we can suggest some options.

Your crossbars need to be at least 30" apart front-to-back and 36"- 42" apart is optimal. This will properly distribute the weight of the tent and its occupants.

There needs to be enough clearance between the roof of your vehicle and the top of your crossbars to be able to fit your arm in so you can tighten the mounting hardware.

We have seen that the stock crossbars on many makes of vehicle do not provide the proper clearance to make installation easy - in these cases an after-market crossbar solution is recommended - email us at info@roofnest.com for suggestions.



### **Installation Instructions**

Step 1

Unbox the Roofnest by removing the top cover on the cardboard box.

Step 2 Remove the plastic film protecting the top and bottom shells of the Roofnest.

Step 3 Open the Roofnest by undoing the latches on one end only and pulling up that end.

Remove the big nylon bag inside the Roofnest containing the mounting hardware and ladder (we include an extra strut as well in case it's ever needed).

Close the Roofnest by pushing or pulling the open end down and fastening the latches. Step 4 Place the Roofnest onto your crossbars. You don't need to worry about lining up your Roofnest just yet.


Please make sure the ROOFNEST logo faces towards the back of your vehicle.

Step 5

Set up your mounting hardware by inserting a bolt into a mounting bracket with the bolt head in the channel of the plate (see photo).



It's easier if you pre-tighten one side of the mounting set so that you don't have to do that while it's under your tent.



### **Installation Instructions**



Begin putting the mounting sets into the two mounting rails on the bottom of the Roofnest – two sets for each corner.

You'll need to lift the Roofnest slightly to get one of the two bolts at each corner onto the other side of your crossbar (see photo).







Place each of the four mounting plates onto the two bolts at each corner and thread the included nuts onto the bolts (see photo - proceed to next step before tightening all the way).



Step 8 Now it's time to orient the Roofnest so that it is centered where you want it. If the mounting hardware is loose then you should be able to move the Roofnest so that it is lined up on your roof where you want it.



Tighten all the mounting hardware hand tight. Drive your car 10-20 miles and check all the nuts to make sure they are still tight - sometimes the Roofnest will shift and so you may need to orient before you tighten again.

Periodically check the mounting hardware to ensure that it stays tight and the Roofnest is secure.

# Now go camping and enjoy!

**Share Your Adventures #Roofnest** 

Roofnest, Itd. 3696 Silverton Street Unit H Boulder, CO 80301 e: info@roofnest.com p: (855)-887-8897 www.roofnest.com

