


PARTS LIST

ATTENTION: Before you begin the assembly, make sure that all parts are included in good condition.


A Backrest, x1




B Seat, x1



C Star Base, x1




D Mechanism, x1



E Hydraulic Gas Lift, x1




F Caster, x5




G Armrest

NOTE: When you are seated on the chair, not looking at it.

X1 Right X1 Left



H Base Cover, x1



(Note: This part might come with the gas lift or attached to the base)

I M6x20mm, x4



(Mechanism)

J M6x30mm, x2



(Armrests)

K M6x35mm, x4



(Armrests)

L M8x20mm, x3



(Backrest to mechanism)

M Allen Wrench, x1




ASSEMBLY INSTRUCTIONS FOR CHAIR MODEL RTA-0098M


ATTENTION:

- ⚠ Follow the instructions step by step.
- ⚠ To avoid misalignments, leave the screws loose and do not tighten them until all are in their respective places.
- ⚠ Do not overtighten or force the screws as they could break, strip, or damage the threads of the holes.
- ⚠ Using the wrong size of screws on a part could result in damage to the screw or the part.


- 1** Insert the casters (F) into the legs of the base (C) using pressure, then place the base cover (H) and the gas lift (E) in the middle of the base as shown.




- 2** Place the seat (B) upside-down with its front towards you as shown. Using screws (I), assemble the mechanism (D) to the seat with its knob facing to the FRONT.



- 3** With the seat positioned as shown, assemble the armrests (G) on their respective sides using the short screws (J) for the inner holes and the longer screws (K) for the outer holes as shown.




- 4** Insert the metal plate of the backrest (A) into the mechanism (D) and secure it with screws (L) as shown.




- 5** Place the seat over the base, making sure the tip of the gas lift enters into the hole of the mechanism.

Tighten well all the screws before you sit on the chair for the first time.



CHAIR'S FUNCTIONS:

- (1) To raise or lower the chair's height, pull UP the RIGHT lever on the mechanism.
The chair goes down while sitting on it, or up if you lift your body.
- (2) To make the backrest recline freely, pull UP the LEFT lever on the mechanism.
To lock the backrest on a specific reclining position, push that lever DOWN.
To unlock and make the backrest recline freely again, pull the lever UP.
- (3) To adjust the tension for the reclining function, turn the mechanism's knob in either direction to apply more or less tension.
- (4) To adjust the armrest height, pull UP the button that is under the armrest and release it once the desired height is reached.



WARNINGS:

- Do not stand up on the chair or use it as ladder.
- Use the chair to seat only one person at a time.
- Do not use the chair if parts are damaged or if screws are loose or missing.
- Do not seat near the edge of the seat and always sit properly on the chair to avoid going beyond your balance point and fall off the chair.
- The chair is intended for teenagers and adults. If small children are using the chair, please keep close observation on them.
- Do not allow small children to play with the chair.
- Not paying attention to these warnings could result in severe injuries.

CARE AND MAINTENANCE:

- To clean the chair it is recommended to use a soft cloth lightly dampened in a solution of smooth soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean any part of the chair.
- Before applying a cleaning agent, test on a small hidden area of the chair, like underneath the seat.
- Do not expose the product to direct sunlight or to extreme environmental conditions.
- Every 4 months, inspect the chair completely and make sure that all screws are tighten.