





MODEL RTA-2027C


ASSEMBLY INSTRUCTIONS










REV.1-FT-8910-0625



Thank you for purchasing our product!

Hardware			
No.	Item		Qty.
I	M6x20		4 Pcs
J	M6x25		4 Pcs
K	M6x35		6 Pcs
L	Ø6mm x Ø16mm x 1mm		12 Pcs

Tools (Included)	
M5, 70mm x 70mm Allen Wrench	

MAIN PARTS LIST				
A Backrest 	B Seat 	C Nylon star base 	D Mechanism 	E Lift cylinder 
F Casters 	G-L Left armrest 		G-R Right armrest 	
			H Covers for lift cylinder 	

* The left metal bracket on the seat is loose, while the right is stiff and can only move once the chair is assembled.



For Support, Assembly Questions & Replacement Parts Within the 48 Contiguous United States:

Please email us at: support@rtaproducts.com



Replacement Parts for International Customers & **AK-HI-PR** orders:
RTA Products will replace the part free of charge, while **the customer is responsible for shipping costs plus any International local taxes or duties.**



technimobili.com




support@rtaproducts.com

ASSEMBLY STEPS

STEP 1


FIRST: Attach F to the legs of C.

THEN: Place E into C and cover it with H.

**STEP 2**

Attach D to B with I and L.

⚠ PAY ATTENTION:
The Knob from D faces
towards the FRONT.




⚠ PAY ATTENTION:
Use the correct screws.

STEP 3

Attach G-L and G-R to A in their respective sides with K.



⚠ VERY IMPORTANT:
Leave the screws loose to allow flexibility for
proper alignment of the pieces in the next step.




ASSEMBLY STEPS

STEP 4

Attach A, G-L and G-R to B with J and K.





⚠ VERY IMPORTANT:
Screw loosely to allow flexibility
for proper alignment; tighten
only after all are in place.



(View from behind)

STEP 5


Join the seat with the base.



STEP 6

FINALLY, tighten the screws K.



(View from behind)



CHAIR'S FUNCTIONS




Pull Handle OUT
to UNLOCK;
Push Handle IN
to LOCK.

Pull Handle UP.



Turn CLOCKWISE for
less tension (-);
COUNTERCLOCKWISE
for more tension (+).
With less tension, the tilting feels easier.

WARNINGS - Not paying attention to the following warnings could result in injuries.




Do not use the chair if the frame parts are damaged, or if any of the screws are loose or missing.



Do not leave babies or toddlers unattended while seated on the chair, always ensure adult supervision. Keep children from playing with the chair for their safety.

CARE AND MAINTENANCE


Clean with a soft cloth lightly dampened in a solution of smooth soap and water.




Do not use solvents or abrasive materials.



Do not expose to direct sunlight or to extreme environmental conditions.



Inspect the chair thoroughly every 4 months and re-tighten the screws.



LIMITED WARRANTY



For details, please visit our website:
Technimobili.com

To file a claim or request information, please email to:
warranty@rtaproducts.com

