

Casters

(F) X1 Base Cover

ASSEMBLY INSTRUCTIONS CHAIR STYLE RTA-3236/3237


PARTS LIST ATTENTION: Before you begin to assemble the product, please make sure that all the parts are included in the package, and inspect them for damages or defects. (A) X1 (G) X4 **Backrest** Screws Seat M6X18 MM (B) X1 (H) X4 Base Washers 0 (C) X1 (I) X1 Allen Wrench Mechanism (D) X1 Gas Lift (E) X5

ATTENTION:

- To avoid misalignments, leave the screws loose and do not tighten them until all are in place.
- Do not overtighten or force the screws as they could break or strip.
- Using the wrong size of screws on a part might cause damage to it.

STEP 1


Insert all the casters (E) into the base (B) using pressure, then cover the base (B) with (F) and place the gas lift (D) in the middle of the base (B).



STEP 3


Place the top parts of the chair over the base parts making sure the gas lift enters into the center hole of the mechanism.

Turning the chair upsidedown to do this is also advisable.



STEP 2

Install the mechanism(C) under the seat using the screws(G)and washers(H).



STEP 4

All the parts must be secured before using the chair for the first time, so make sure that all the screws, bolts are tightened.

The top and base parts will stay together by pressure after seating.





LIFT FUNCTION:

- To raise or lower the chair's height: Pull the lever UP with force. The chair will go down while sitting on it, or up if you lift your body.

WARNINGS:

- Do not stand up on the chair.
- Do not use the chair as a ladder.
- Use for seating only one person at a time.
- At least every 4 months, check all bolts, screws and knobs to be sure they are tight. Do not use if parts are loose, damaged or missing.
- Failure to follow the above warnings could result in serious injury.
- Do not apply solvents or polishers directly to the chair parts to clean them. Instead, use a soft damp towel with a solution of mild soap and water.