

ATTENTION:

▲ Follow the instructions step by step.

ASSEMBLY INSTRUCTIONS FOR CHAIR MODEL RTA-KS41

PARTS LIST

ATTENTION: Before you begin the assembly, make sure that all parts are included in good



CHAIR'S FUNCTIONS:

To raise or lower the chair's height, pull UP the lever that is under the seat. The chair goes down while sitting on it, or up if you lift your body. NOTE: This chair does not recline.



WARNINGS:

This chair is intended for children, however, it is strongly recommended to take the following safety precautions to avoid injuries:

- Use the chair to seat only one child at a time.
- Do not let the child stand up on the chair.
- Do not let the child play with the chair as if it was a racing vehicle.
- Do not use the chair if parts are damaged or if screws are loose or missing.

CARE AND MAINTENANCE:

- To clean the chair it is recommended to use a soft cloth lightly damped in a solution of smooth soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean any part of the chair.
- Before applying a cleaning agent, test on a small hidden area of the chair, like underneath the seat.
- Do not expose the product to direct sunlight or to extreme environmental conditions.
- Every 4 months, inspect the chair completely and make sure that all screws are tighten.