

DABPRESS™

D.I.Y HYDRAULIC PNEUMATIC PRESSES

QUICK START GUIDE

Models: bj3t33, bj3t33 Pro, bj6t35



1. Move hydraulic rosin press to working area. Tip: Be sure to protect your working area from scratches during operation.
2. Plug in power to the Rosin Control Box, turn on both platen power switches, and main power.
3. Set desired temperature on Rosin Control Box. Recommend 160-200F for fine material, 180-220F for flower
4. Close the release valve on bottle jack using the notched end of the jack handle. Turn it clockwise until it's closed.
5. Insert jack handle into socket

6. Prepare your puck
7. Insert Parchment paper in between open plates, then insert your puck.
8. Pump the jack handle down and up slowly (finer material must apply pressure at a much slower speed!). Continue to slowly apply pressure until either the color darkens considerably or you feel it is already very tight.
9. Start a timer for 90 seconds. Check for additional flow during this time, and determine when to end your pressing time.
10. Remove the jack handle from the socket and open the release valve by turning it counter clockwise ½ turn.
11. Remove parchment paper and puck carefully from the open platens.



12. Collect your material, a cold plate from the freezer may help in your collection
13. Place collection in storage container.
14. Power off Rosin Control Box if your pressing time is over. Repeat steps 3-12 to continue working.

Email: support@dabpress.com - Tech Support (719)214-2100