

## TROUBLESHOOTING

If the flashlight does not turn on or works intermittently:

- Replace the batteries.
- Make sure the tail cap is twisted on tightly and batteries are inserted correctly.

If the flashlight flickers:

- Make sure the tail cap is twisted on tightly.

If the light appears dim or faded:

- Replace the batteries.

If the problem persists, possible LED Failure. Contact GearLight for a replacement.

## MAINTENANCE

Inspect the flashlight monthly and carefully remove any damaged batteries and clean any corrosion. If the flashlight is used less than once a month, remove the batteries between uses. Lubricate all threads and rubber O-rings with petroleum jelly twice yearly.

## WARRANTY AND LIMITATION OF LIABILITY

### Limited One-Year Warranty

GearLight warrants this product for one year from the date of purchase against any defects in material or workmanship. This warranty does not cover normal wear and tear, nor damage resulting from misuse or neglect. We will, at our discretion, repair, replace, or refund the purchase price of this product should we determine it to be defective.

### Limitation Of Liability

Liability limited to the purchase price of this product. GearLight shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

V2

# GEARLIGHT

## S100 LED POCKET FLASHLIGHT

## Operation Guide

FOR YOUR SAFETY, READ BEFORE OPERATING



### Package Contents:

- 2x GearLight S100 LED Pocket Flashlights
- 1x Operation Guide

**WARNING:** To avoid eye injury, do not stare directly into the beam or shine the flashlight beam directly into anyone's eyes.  
This product is not designed, intended, or recommended for children.



## GETTING STARTED

### AAA Battery Installation

1. Unfasten the tail cap.
2. Insert 2 AAA batteries with the positive (+) end first.  
Always install batteries with the positive (+) end facing the LED end and the negative (-) end facing the tail cap end of the flashlight.
3. Refasten the tail cap.



**WARNING:** Always follow the battery manufacturer's instructions as to the proper usage, handling, storage, and disposal of batteries. Use only batteries from a reputable manufacturer. Do not mix different brands or types of batteries in the same flashlight. Replace all batteries at the same time. Failure to follow safety instructions may result in personal injury and damage to property.

## OPERATION

### On/Off

- To turn the flashlight on, press down firmly on the red power button located on the tail of the flashlight until you hear a click.
- To turn the flashlight off, press down firmly again until you hear a click.



## NOT HAPPY? NEED TO RETURN?

Avoid the hassle of shipping the product back. Contact us at [support@gearlight.com](mailto:support@gearlight.com) within 1 year of the purchase date for a free replacement or full refund.

**We respond to all inquiries within 24 hours.**