TROUBLESHOOTING

If the flashlight does not turn on, or works intermittently:

- · Replace the batteries.
- Make sure the tail cap is twisted on tightly and batteries are inserted correctly.

If the flashlight flickers or changes modes automatically:

Make sure the tail cap is twisted on tightly.

If the light appears dim or faded:

• Replace the batteries.

If the problem persists, possible LED Failure. Contact GearLight for a replacement.

MAINTENANCE

Inspect the flashlight monthly and carefully remove any damaged batteries and clean any corrosion. If the flashlight is used less than once a month, remove the batteries between uses. Lubricate all threads and rubber O-rings with petroleum jelly twice yearly.

GEARLIGHT

TAC1 LED TACTICAL FLASHLIGHT

Operation Guide

FOR YOUR SAFETY, READ BEFORE OPERATING



WARRANTY AND LIMITATION OF LIABILITY

Limited One-Year Warranty

GearLight warrants this product for one year from the date of purchase against any defects in material or workmanship. This warranty does not cover normal wear and tear, nor damage resulting from misuse or neglect. We will, at our discretion, repair, replace, or refund the purchase price of this product should we determine it to be defective.

Limitation Of Liability

Liability limited to the purchase price of this product. GearLight shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. IMPORTANT SAFETY NOTICE: Lithium-ion batteries are potentially hazardous and can present a fire, explosion, and burn hazard. By using lithium-ion batteries, you agree that GearLight shall not be liable for any incidental or consequential damages arising from, relating to or connected with the use of lithium-ion batteries. If you do not agree with these conditions, please use only alkaline or NiMH rechargeable batteries.

Package Contents:

2x GearLight TAC1 LED Tactical Flashlights 2x Battery Tubes (Batteries Are Not Included) 2x AAA Battery Holders (Inside Flashlights) 1x Operation Guide 1x Warranty Card WARNING: To avoid eye injury, do not stare directly into the light beam or shine the beam directly into anyone's eyes. This product is not designed, intended, or recommended for children or hazardous environments.



GETTING STARTED

AAA Battery Installation

 Unfasten tail cap and remove battery holder.
Insert 3 AAA batteries following the correct polarity (+,-) marked on the battery holder.
Insert the battery holder back into the flashlight with the positive (+) end first.



WARNING: Always follow the battery manufacturer's instructions as to the proper usage, handling, storage, and disposal of batteries. Use only batteries from a reputable manufacturer. Do not mix different brands or types of batteries in the same flashlight. Replace all batteries at the same time. Failure to follow safety instructions may result in personal injury and damage to property.

18650 Lithium-ion Rechargeable Battery Installation (See Warning)

1. Insert one 18650 battery inside the 18650 clear battery tube.

2. Insert the combined 18650 battery and clear tube into the flashlight with the positive (+) end first.



WARNING: Lithium-ion batteries can present a fire, explosion, and burn hazard. Use only 18650 battery cells with a protection circuit produced by Panasonic, Sanyo, Sony, Samsung, or LG. Remove the battery when the flashlight is not in use. The use of other cell manufacturers or the failure to follow the battery manufacturer's safety instructions may result in fire, explosion, personal injury, and damage to property. **CAUTION:** The flashlight may become warm or hot after extended periods of use. This is typical for high-powered flashlights and does not cause damage to the flashlight.

OPERATION

WARNING: Remove the batteries if the flashlight is not working properly. Failure to do so may result in personal injury and damage to property.

On/Off

- To turn the flashlight on, press down firmly on the red power button located on the tail of the flashlight until you hear a click.
- To turn the flashlight off, press down firmly again until you hear a click.
- There is a single lighting mode. (High)



Zoom

1. Hold both ends of the flashlight; gently twist and pull each end away from the other.

2. Pull the two ends away from each other to zoom in and push the two ends together to zoom out.

