

TROUBLESHOOTING

If the light does not turn on or works intermittently:

- Make sure the power button is not stuck.
- Recharge the light only if no damage is observed.

If the light does not charge:

- Check the USB charging cable connection and the power source.
- Note: A computer in sleep mode will not charge the light.

If the problem persists: Replace the USB charging cable.

MAINTENANCE

When the lights are not in use, store them with a moderate level of charge and in a cool place away from flammable materials. Once every few months, discharge the batteries fully and recharge.

WARRANTY AND LIMITATION OF LIABILITY

Limited One-Year Warranty

GearLight warrants this product for one year from the date of purchase against any defects in material or workmanship. This warranty does not cover normal wear and tear, nor damage resulting from misuse or neglect. We will, at our discretion, repair, replace, or refund the purchase price of this product should we determine it to be defective.

Limitation Of Liability

Liability limited to the purchase price of this product. GearLight shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

GEARLIGHT

S400 RECHARGEABLE LED BIKE LIGHT SET

Operation Guide

FOR YOUR SAFETY, READ BEFORE OPERATING



Package Contents:

1x GearLight S400 Rechargeable LED Headlight
1x GearLight S400 Rechargeable LED Taillight
2x USB Charging Cables
1x Operation Guide
1x Warranty Card

WARNING: To avoid eye injury, do not stare directly into the light beam or shine the beam directly into anyone's eyes. The lights are not a replacement or substitute for your bicycle's original reflectors.

HEADLIGHT OPERATION



On/Off

To turn the headlight on, press down on the power button located on the top of the headlight.

To turn the headlight off, press down on the power button to cycle through all the lighting modes until the light is off.

Switching Modes

There are five different lighting modes. (High, Medium, Low, Strobe, and High with Strobing Side Lights)

To switch through the different lighting modes, press down on the power button to alternate through the five modes.

How to Mount the Headlight

Wrap the silicone strap around the handlebar and attach it to the strap hook.



TAILLIGHT OPERATION

On/Off

To turn the taillight on, press and hold the power button for two seconds.

To turn the taillight off, press and hold the power button for two seconds.

Switching Modes

There are four different lighting modes. (High, Low, Strobe, and Fast Strobe)

To switch through the different lighting modes, press down on the power button to alternate through the four modes.

How to Mount the Taillight

Wrap the silicone strap around the bike frame and attach it to the strap hook.



HOW TO CHARGE THE HEADLIGHT AND TAILLIGHT

WARNING: Lights contain lithium batteries that can present a fire hazard. Do not charge or store the lights near flammable materials. Do not overcharge the lights; unplug the lights once they are fully charged or if left unattended. Use only UL-Listed charging adapters rated at 5V 1A max. Do not use or charge the lights if they are wet or damaged. Do not disassemble or modify the lights. Failure to follow safety instructions may result in fire, personal injury and damage to property.

Note: Fully charge the lights before their first use.

1. Lift the rubber cover to locate the USB charging port.
2. Connect the light to the USB charging cable.
3. Connect the USB charging cable to a device with a USB charging port, such as a computer or cellular phone charger. See warning.
4. The headlight is fully charged in approximately 3 hours and the indicator light will turn solid green. The taillight is fully charged in approximately 2 hours and the indicator light will turn off.
5. Unplug the USB charging cable when the battery is fully charged.

Note: Make sure the rubber cover is secured over the USB charging port when the lights are in use. Do not use the lights in heavy rain.