

ISABELLA
KRON

USER MANUAL

DIVAUGUSTA
by
ISABELLA KRON®

Swiss Made

ISABELLA KRON®

DIVAUGUSTA

Swiss Made watch

Movement

Hour and minute indication

Premium Swiss quality quartz (Reparable)

Button cell battery

1.5 V (V335, 335, SR512SW)

36 months of power reserve

Case

Stainless steel 316L or stainless steel 3N color gold PVD plating. 5 bar (50 m / 165 ft) water-resistant

Glass

Hardened K1 mineral crystal

Strap

Leather wristband handcrafted in Italy.


Single strap with loops: Small (20x1.8cm) or Medium (25x1.8cm)

Double strap with loops: Small (34x1.8cm) or Medium (39x1.8cm)



Setting the time

Pull the crown out to position B and turn it in either direction until the desired time is displayed. When the crown is pulled out to position B, the movement stops. Once the time is set, push the crown back into position A.



Attaching the strap

Pass one end of the strap through the buckle at 12 o'clock from underneath (1), fix the pin on the desired length (2) and secure it by passing it again through buckle (3). Place the watch on your wrist and adjust the strap length by repeating the process with the other end of the strap through the buckle at 6 o'clock.

Technical information

ISABELLA KRON® watches are delivered with a power reserve of 3 years in continuous use, though this can slightly vary depending on the habits of the wearer and the ambient temperature. Similarly, the ambient temperature may affect the accuracy of quartz movements, causing variations of around -10 to +20 seconds per month.

Water-resistance

ISABELLA KRON® watches are designed to withstand a pressure of up to 5 bar (50 m / 165 ft). A watch cannot be permanently guaranteed absolutely water-resistant. It may be affected by ageing of the gaskets or by an accidental impact on the watch. **We recommend to have the watch's water resistance checked once a year by an authorized retailer.**

Care and maintenance

Temperature

Do not expose your watch to sudden temperature changes (exposure to sunlight followed by immersion in cold water) or extreme temperatures (over 60°C (140°F) or below 0°C (32°F)).

Magnetic fields

Do not expose your watch to intense magnetic fields such as those generated by loudspeakers, mobile phones, computers, refrigerators or other electromagnetic appliances.

Shocks and impacts

Avoid thermal shocks or impacts, since they may harm your watch. **In the event of a violent impact please have your watch checked by an authorized retailer.**

Harmful products

Prevent your watch from coming into any direct contact with solvents, detergents, perfumes, cosmetic products etc., since they may damage the bracelet, the case or the gaskets.

Cleaning

We recommended to clean your watch regularly (except for the leather strap) using a soft cloth and lukewarm soapy water. After immersion in salty water, rinse your watch in fresh water and leave it to dry completely.

Storing

If your watch is not worn for a few weeks or months, we recommend to pull the crown out to the last stop before storing it. This will reduce energy consumption.

Services

Like any precision instrument, a watch must be serviced regularly for optimum operation. As a general rule, we recommend to have a watch checked every 3 to 4 years by an authorized retailer. However, please note that depending on the climate and the conditions of use of the watch, a shorter interval may be required.

Collection and treatment of end of life quartz watches*



This symbol indicates that this product should not be disposed of as household waste. It must be returned to an approved collection point. By following this procedure you will contribute to safeguarding the environment and human health. Recycling the materials will help to conserve natural resources.

Battery type: silver oxide and zinc button cell.

* Valid in European Community member states and in any countries with comparable legislation.

Please find detailed Terms & Conditions on <https://isabellakron.com>

