

A WARNING

DO NOT USE THIS PRODUCT UNLESS YOU HAVE READ AND UNDERSTAND THESE WARNINGS, CAUTIONS, AND INSTRUCTIONS WHICH ARE FOR YOUR SECURITY AND PROTECTION. THIS INFORMATION MAY BE SUBJECT TO CHANGE AT ANY TIME. FOR CURRENT UPDATES, PLEASE VISIT OUR WEBSITE AT: WWW.CABRINHAKITES.COM

IF YOU ARE BELOW THE AGE OF 18, YOU SHOULD HAVE YOUR PARENT OR GUARDIAN READ THESE WARNINGS, CAUTIONS AND INSTRUCTIONS AND SHOULD NOT USE THIS PRODUCT UNLESS YOU ARE UNDER THE PROPER GUIDANCE AND SUPERVISION OF SUCH A PERSON.

The use of this product exposes the user to many unavoidable and unexpected risks, injury, DANGERS and HAZARDS. The suppliers of this product are not responsible for any damage to property or any personal injury caused by any use, misuse, abuse or irresponsible use of this product by the user.

Kiteboarding is a HAZARDOUS sport. Power kites and their lines and control equipment can be DANGEROUS to flyers and to anyone in the vicinity of their use. Kiteboarding must be taken seriously and we recommend that, at least in the early stages of your use, you seek the guidance of professional instructors and experienced kiteboarders. Improper and/or unreasonable use of this kite may result in DEATH or SERIOUS INJURY to ANY part of your body and to OTHERS. Do NOT use your kite near power lines, airports, buildings, automobiles, trees, streets, parking lots, rocks, piers, breakwaters, buoys, etc. and keep your kite fly lines away from people and ALL obstacles. Always fly in an open area and observe wind and weather conditions, particularly in circumstances where you may encounter offshore, onshore, variable or strong winds. Do NOT attempt to use your kite on water until you are confident and comfortable with the use of a trainer kite on land. Spend time to become familiar with the operation of your kite and remember that you are responsible for its operation and for the security of those around you. As you learn the sport, work within your own limitations and do NOT exceed them. If you intend to use the kite on water, always use appropriate protective gears and flotation devices and do NOT attach yourself or tie yourself permanently to the kite lines. The kite is NOT intended for use as a flying device nor indeed is it intended as a means of flotation.

RECOMMENDED KITESURFING PRACTICE:

Kiteboarding is an extremely diverse sport, with many disciplines and ability levels. As with all sports, there can be certain inherent risks. The following contains key security points to remember when operating your Cabrinha kite.

- Kiteboarding is a HAZARDOUS activity and the use of Kiteboarding equipment involves the risk of serious personal injury to any part of the user's body or death.
- Injuries are an INHERENT RISK of kiteboarding and the participation in kiteboarding implies the user's acceptance and assumption of those risks.
- Children should ALWAYS be under adult supervision.
- It is strongly recommended that beginners take lessons.
- ALWAYS inspect your equipment for signs of wear and tear each time before use, particularly all lines, canopy, bladders, screws and fittings.
- If ANY products are found to show signs of wear & tear, STOP using the product immediately and repair or replace before further use. If in doubt about any signs of wear & tear, please contact your local vendor. Contact details are available from www.cabrinhakites.com
- NEVER place yourself in a situation where breakage of any one of the various kiteboarding components would pose a risk to yourself or others, or make it difficult to return to the shore securely & unassisted.
- Make sure you use properly designed and manufactured parts from reputable suppliers.
- Take time to study the conditions including sea state, tides, currents, weather conditions and forecasts before you decide to go sailing. Beware of sailing in offshore, onshore, variable or strong winds.
- Familiarize yourself with any new location before venturing onto the water. Ask the locals to tell you about any hazards.
- Watch out for other beach users, especially swimmers and small children. Make sure you keep your board and rig under control at all times and that they don't get blown about on the beach or in the water.
- Always use appropriate protective gear and flotation devices. Wear the correct protective clothing for the conditions such as a wetsuit or a UV top.
- We STRONGLY recommend wearing a kiteboarding specific helmet
- Make sure someone knows where you've gone & when you are expected back – always sail with a buddy.
- Be aware of the conditions as they change. ALWAYS return to the beach if there is a significant change in the conditions. I.e. wind dropping or wind & waves increasing.
- As you learn the sport, work within your own limitations and do NOT exceed them.
- Do NOT alter, modify or change this product.
- This product is designed and manufactured only for kiteboarding on water or snow.
- Keep these warnings, cautions and instructions for future reference.
- The following contains key security points to remember when operating your Cabrinha kite, and associated kiteboarding equipment on water, land or snow.

LIMITED WARRANTY

Cabrinha Kitesurfing warrants that this product, when it is purchased from an authorized Cabrinha Kitesurfing dealer by a retail customer, will be free from defects in materials and workmanship for a period of one (1) year from the date of purchase by the original retail customer. This warranty is solely for the benefit of the original retail purchaser and may not be assigned.

For retail customer Limited Warranty claims, proof of purchase from an authorized Cabrinha Kitesurfing dealer is required. If the date of purchase cannot be established, Cabrinha Kitesurfing will make a determination based upon the last production year of the particular model, or on the condition of the equipment claimed.

If you have any questions about the Cabrinha Kitesurfing Limited Warranty or procedures for making claims thereunder, please contact Cabrinha Kitesurfing at www.cabrinhakites.com The Cabrinha Kitesurfing Warranty Center will determine if a product is covered under this Limited Warranty. If covered, Cabrinha Kitesurfing will, at Cabrinha Kitesurfing's sole option, repair or replace the product in question.

All returns must be made through Cabrinha Kitesurfing authorized dealers within 30 days of the defect becoming apparent. Cabrinha Kitesurfing does not accept returns directly from customers. Customers must call for a Return Authorization Number before returning any product under this Limited Warranty. All authorized returns must be sent to a Cabrinha Kitesurfing's Warranty Center at the country's main distribution warranty office, freight prepaid. Cabrinha Kitesurfing will pay the freight for the return shipment. Return shipment will either be consolidated together with the authorized retailer next shipment, or paid by Cabrinha Kitesurfing, at Cabrinha Kitesurfing's sole option.

Any repair or replacement of any product under this Limited Warranty is not available for ordinary wear and tear, including scratches or paint chipping, or for any damage caused by misuse, abuse, unauthorized modification or repairs, accident, heat, excessive exposure to sunlight, excessive exposure to cold, improper handling, storage, maintenance or care; incorrect setup, use in commercial, rental or teaching environments; use in reef wave, waves, shore break or off the water; any blow or impact with a hard object or any other irresponsible use.

THE FOREGOING LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OF QUALITY AND PERFORMANCE, WRITTEN, ORAL OR IMPLIED AND ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED. IN NO EVENT SHALL CABRINHA KITESURFING BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, STATUTORY OR EXEMPLARY DAMAGES, WHETHER IN CONTRACT, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE including, without limitation, loss to property other than this product, loss of use of said product, or other property or other economic losses. Cabrinha Kitesurfing shall not be liable for contribution or indemnification, whatever the cause.

Some jurisdictions do not allow limitations on how long an implied warranty lasts and/or the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to particular customers. Cabrinha Kitesurfing's obligations under any warranty shall be limited, to the greatest extent allowed by law, as provided in this Cabrinha Kitesurfing Limited Warranty. This Limited Warranty gives you specific legal rights; you may also have other rights, which vary from one jurisdiction to another.

REGISTER YOUR CABRINHA PRODUCT ONLINE AT:

www.cabrinhakites.com

TWIN TIP BOARD ACCESSORY INSTALLATION GUIDE

Inventory list

- 1 - Board handle (n/a to Custom)
- 4 - Twin tip specific fins
- 10 - M6x16mm mounting screws

Tools needed:

P3 Screwdriver

NOTE: Do not use power tools to assemble your board. You will run the risk of cross threading the inserts. Doing so will void your warranty.

Before getting started:


- Remove all contents from the accessory package. Identify each item from the inventory list above.
- Screws are located in the internal pocket of the packing bag.
- Check each insert in the board.
- Carefully thread a handle mounting screw into each insert to be sure it threads easily and the threads are clear of any debris.
- Carefully thread a fin mounting screw into each fin hole to be sure it threads easily and the threads are clear of any debris.

Handle mounting

1. Align the handle to the correct alignment so the insert is clearly visible.
2. Put the screw in place and tighten. Some downward force maybe needed.

Fin mounting

1. Identify the correct orientation of each fin by having the short, pointy side facing toward the center of the board and the taller, rounded side facing toward the tip of the board.
2. Align the fin until you can see the fin holes through the screw holes near the board's tips.
3. Put the screws in place and tighten.
4. Repeat these steps for each of the other 3 fins.



SURF BOARD ACCESSORY INSTALLATION GUIDE

Inventory list

- 2 - Surf straps
- 5 - Surf strap mounting screws
- 4 - Stainless steel mounting washers
- 4 - Anti-twist washers
- 3 or 4 - Surf Fins (Dependent on board model)
- 1 - Fin Key
- 1 - Front pad set

Tools needed:

P3 Screwdriver

NOTE: Do not use power tools to assemble your board. You will run the risk of cross threading or stripping the inserts. Doing so will void your warranty.

Before getting started:


- Remove all contents from the accessory packaging attached to the board. Identify each item from the inventory list above.
- Check each insert in the board.

Mount straps

1. Identify the correct orientation of each strap. The Cabrinha Surf Straps are designed to have the wider section of the strap facing out toward the tip and tail of the board. This orientation can be adjusted to fit loose so as to allow easier twisting of either foot while offering maximum comfort and performance. Those who desire a tighter, more locked in feel may prefer the wider portion of the strap over the inside of the foot instead.
2. Slide one of the stainless washers over the desired mounting position on the strap.
3. For Skillit and Trigger only: When mounting the back foot strap, it will be necessary to use 2 screws to secure the side of the strap closest to the tail of board. For this step, it is not necessary to use one of the anti twist pieces. For Squad and Subwoofer, please proceed directly to step 4.
4. Insert one of the anti-twist pieces into the matching position of the strap from the underside. The two posts should secure the stainless washer into place.
5. Thread one of the mounting screws into the washer
6. Screw the strap into place on the board in the desired location making sure the screw is tight.
7. Repeat this process for the other side, then for the other strap accordingly.

Fin mounting

1. Identify the correct orientation of each fin. (side fins have the rounded side of the foil, facing out towards the rail.)
2. Using the provided fin key, un-tighten the fin screws on the bottom of the board (situated at the front of the box). Do this until you can see that there is clearance for the fin to enter the fin box).
3. Insert the fin tail first and then push down the front section. Tighten the screws finger tight. Please be aware of overtightening the screws.



TO GIVE YOUR BOARD A LONG LIFE

Twin Tip Care and Maintenance.

- Use Recommended Cabrinha fins, foot straps and Accessories.
- Tighten the foot strap and fin screws firmly. Do not over tighten.
- The foot strap and fin screws are subject to extreme loads and forces, and should be checked regularly if still tight.
- All boards have been designed around the Cabrinha strap range, Scope and Hydra. With the exception of the Custom they are not intended for use with Wakestyle Bindings.
- If you choose to mount bindings on the Custom board make sure to use M6 Screws (Metric)
- Regularly check your board for holes, coming from any damage.
- In case you find any damage make sure these are sealed and fixed properly before further use.
- Store your Cabrinha board in a board bag to prevent unnecessary sun exposure, scratches and other wear and tear while the board is not in use.
- While this Cabrinha board has been built tough, it's not indestructible. Damage caused by use on Kickers, Sliders, Objects is not coverable by warranty.

Surf Range Care and Maintenance.

This Cabrinha Surfboard is a light weight, high performance product designed for kitesurfing and surfing in and around waves.

The surfboard is NOT intended for sent jumps such as kiteloops, etc. Under normal use, the board will dent under the feet. Like any light weight, high performance surfboard of this type, breakage is possible on hard landings. Direct impact of a large wave can break the board. Direct impact with a hard object such as a rock or reef can damage the board.