

BEFORE USING THIS PRODUCT: PLEASE READ, UNDERSTAND AND FOLLOW THESE INSTRUCTIONS.

This product has been designed to give hours of safe and effective cooling, however for maximum benefit and reliable service follow these simple steps.

Operation:

- 1. Place around your neck, with the vents on the band facing upwards.
- 2. Press the power button for 3 speed settings and again for off.
- 3. Using on the lowest speed setting will prolong the battery life.





Warnings:

- 1. This is not a toy, children should only use under direct supervision of a responsible adult.
- 2. Take care when unfolding the fan, excessive force will damage the hinge mechanism
- 3. Take care to avoid hair becoming caught in the air cavity.
- 4. Do not tamper, dismantle or modify the fan.
- 5. Store the fan at normal room temperature, excessive heat may reduce the battery and product life.
- 6. Do not poke objects into the fan cavity or the fan will become damaged.
- 7. Do not use the product during charging.
- 8. Remove from charge socket when fully charged
 - do not leave on prolonged charging.



Contact: Valiant is a trading name of The Accessory Outlet Ltd.

The helpline is a one-to-one service available between the hours of: Monday to Friday: 8.30am - 4.30pm Tel: +44 (0) 1763 284181 Email: contact@simplyvaliant.co.uk Website: www.simplyvaliant.co.uk

To ensure that your call is handled quickly and efficiently, please ensure you have the model number (FIR582) and any other relevant information regarding your product to hand at the time of your call. Please retain these instructions for future use.



Charging:

The product has an internal non serviceable

- Li-Ion battery for long life and simple recharging.
- 1. Connect to any USB supply using the type C charge Lead (supplied).
- 2. The charge socket will glow RED during charge, when fully charged the light will extinguish.
- 3. Disconnect after charging, this is normally between 3 and 4 hours. Do not leave on charge overnight.
- 4. It is normal for the product to warm up slightly to a maximum of 40C
- 5. Discontinue use if the product exceeds 60C

Cleaning and maintenance:

- 1. Clean only with a damp or dry cloth, do not immerse in water.
- 2. Do not use detergents or solvents to clean.
- 3. Dust may accumulate in the vents, carefully remove using a fine brush.
- 4. Do not clean while charging.

Disposal:

Electrical equipment and batteries should never be disposed of with general household waste. They must be separately collected for proper disposal.



The symbol on the product reminds you of the need to dispose of the product correctly at the end of its life. Please dispose of at your local recycling centre.


Warranty:

This product is guaranteed by Accessory Outlet for a period of 1 year from the date of purchase under a Limited Warranty Agreement. During this period if there is a defect due to faulty materials or workmanship, the retailer from whom you purchased it will replace it with the same or a similar model on production of your purchase receipt or proof of purchase. This guarantee does not cover defects arising from accidental damage, misuse or wear and tear, and is available only to the original purchaser of the product. This does not affect your statutory rights.

Specification:

Input: 5v 1A USB power supply Battery: Li-lon 4000 mAh Charge time: 3-4 Hours Run time: 5-18 hours depending on speed setting

Ť VALIANT



FIR582 RECHARGEABLE FOLDING NECK FAN Operating Instructions