

BOB-A-QUE

Portable Outdoor Cooking Grill
A Product of Paumco Products, Inc
500 Congress St W
Maple Lake, MN 55358

Please read entire instructions before assembly and use.

⊖WARNING⊖

- Grill is for outdoor use only
- Keep small children away from grill or open fire at all times
- Grill is recommended to hold up to 8 pounds of food
- Grill surfaces may become hot during use and cause serious personal injury if not handled properly

⊖ CAUTION ⊖

- Some parts may contain sharp edges. Wear protective gloves if necessary.


ASSEMBLY INSTRUCTIONS

****To prevent serious injury, assemble grill before lighting fire. ****

1. Insert shaft (leg) into ground with step pointing towards fire pit.
2. Assemble clip on arm by sliding clip over arm. Hole in clip should match hole in arm. See sketch on next page.
3. Assemble arm on leg by sliding arm over the upper end of leg and through the hole in the clip and the arm.
4. Rotate arm away from fire pit to allow for assembly of grill.
5. Place grill into hole on end of arm.
6. Rotate grill over fire pit.

NOTE: SWING ARM HAS SLIGHT BEND TO ALLOW FOR LEVEL COOKING

Notes: Arm can be adjusted vertically by pressing down on clip. It is not necessary to apply downward pressure with opposite hand on the grill arm at the same time. In fact, using your opposite hand to lift the grill arm up slightly while pressing the clip down with your dominant hand allows the arm to slide more freely. During first few uses you may notice a few scratches on the grill leg from the movement of the grill. This is normal and harmless to the grill life. Arm can be adjusted horizontally simply by pushing the grill arm in desired direction.



Before Cooking for First Time

Allow grill surface to heat over high temperature fire for 15-30 minutes. This will heat-clean the grill and eliminate any odor from paint finish of grill.

Cleaning Instructions

Allow grill to cool completely before cleaning

Frequency of cleanup is determined by how much the grill is used.

To clean grill, cover work area with cloth. Use a wire brush or scrapper to remove residue from grill surface. Wipe away loosened residue from grill.

Storing Instructions

Allow grill to cool completely before storing

1. Remove grill from arm and place into box
2. Press down on clip with your thumb while lifting arm off of shaft and place into box.
3. Pull shaft out of ground. Wipe off any dirt from base and place shaft into box.
4. Cover box and store.

Warranty Information

Bob-A-Que is manufactured by Paumco Products Inc.

Paumco Products, Inc. warrants to the original consumer- purchaser that this product shall be free from defects in workmanship and materials under normal and reasonable use and correct assembly for a period of one (1) year from date of original purchase.

Paumco Products will, at its option, refinish or replace any product or part found to be defective during the warranty period. Paumco Products may require you to return the part(s) claimed to be defective, for its inspection, freight or postage prepaid.

Paumco Products requires proof of purchase on all warranty claims.

This warranty does not include the cost of any inconvenience or property damage due to failure of the product and does not cover damage due to misuse, abuse, accident, damage arising out of transportation of the product, or damage incurred through commercial use of the product. This express warranty is the sole warranty given by Paumco Products. Paumco Products' maximum liability, in any event, shall not exceed the purchase price of the product paid by the original consumer-purchaser.

Customer Service Center

If you need assistant or replacement parts, please call 1-866-55-GRILL or Write to:

Paumco Products, INC
BOB-A-QUE Dept.
500 Congress St. W
Maple Lake, MN 55358