



wildflowersex.com/manuals


© 2021 Boyajian Products, LLC dba Wild Flower
Wild Flower and Enby are trademarks or registered trademarks of
Boyajian Products, LLC. All rights reserved.

flower Enby 2

Instruction Manual

Say Hello To Enby™ 2

Enby™ is a vibrator designed to be used in many ways, with any anatomy.



Using Enby™ 2

Enby[™] has a single button that controls the vibration settings. Press and hold the button for 2 seconds to power on Enby[™]. Quickly press the button once more to start vibrations. Press the button again to cycle through the different speeds and patterns. Press and hold the button for 2 seconds to turn Enby[™] off.

Charging Enby™ 2

For best performance, fully charge Enby™ before use.

To charge Enby[™], connect the included magnetic charging cable to the metal contacts on the toy. Then plug the cable into any standard 5V USB power source. Enby[™]'s battery lasts between 1.5 and 2 hours. When Enby[™] is charging, its light will blink. When fully charged, it will remain illuminated.

Ways to Try Enby™ 2

Lay Enby™ down on a flat surface (a bed is perfect) and grind on its contoured hump.
Adjust pressure by shifting your body weight.



Tuck Enby[™] inside a harness or underwear to add stimulating vibration for the wearer. Enby [™]'s flexible body and tip wraps and contours comfortably to your body.



Flex and curl Enby™'s wings to grab, stroke, and massage. To ensure a good grip, only apply lube to the bottom ribbed side of Enby™ when using in this way.



1 Year Warranty

Wild Flower warrants your toy for a period of one year from the date of original purchase against any defects due to faulty materials or workmanship. If the product fails during the warranty period, Wild Flower will repair or replace the toy free of charge.

For more information visit wildflowersex.com/warranty

Cleaning Enby™ 2

We recommend washing your Enby™ with warm water and a gentle soap or water based toy cleaner.

DO NOT use alcohol, petroleum, or acetone products on your toy.

Warnings

DO NOT overbend. It is ok to bend and flex EnbyTM's wings.

DO NOT use silicone-based lube with Enby™.

DO NOT wash Enby™ in the dishwasher.

DO NOT boil, bake, or microwave.

DO NOT expose to extreme temperatures (hot or cold)