


©2021 Boyajian Products, LLC dba Wild Flower Wild Flower and Willow are trademarks or registered trademarks of Boyajian Products, LLC. All rights reserved.

# flower Willow

Instruction Manual

# Say Hello To Willow™

Willow<sup>™</sup> is a G-spot and prostate vibe with an ergonomically balanced handle that rocks easily in your hand.



# Using Willow™

Willow<sup>™</sup> has a single button that controls the vibration settings. Press and hold the button for 2 seconds to power on Willow<sup>™</sup>. Quickly press the button once more to start vibrations. Press the button again to cycle through the different speeds and patterns. Press and hold the button for 2 seconds to turn Willow<sup>™</sup> off.

# Charging Willow™

For best performance, fully charge Willow™ before use.

To charge Willow<sup>™</sup>, connect the included magnetic charging cable to the metal contacts on the toy. Then plug the cable into any standard 5V USB power source. Willow<sup>™</sup>'s battery lasts between 1.5 and 2 hours. When Willow<sup>™</sup> is charging, its light will blink. When fully charged, it will remain illuminated.

#### Ways to Try Willow™

Insert Willow™ and rock it back and forth to stimulate your g-spot or prostate.



The soft ridges on the tip correspond with the internal ridges and folds of the body, while the firm shape delivers pressure and vibration.



Willow<sup>™</sup> can also be used externally for those who find reaching external areas with smaller toys difficult.



#### 1 Year Warranty

Wild Flower warrants your toy for a period of one year from the date of original purchase against any defects due to faulty materials or workmanship. If the product fails during the warranty period, Wild Flower will repair or replace the toy free of charge.

For more information visit wildflowersex.com/warranty

# Cleaning Willow™

We recommend washing your Willow™ with warm water and a gentle soap or water based toy cleaner.

DO NOT use alcohol, petroleum, or acetone products on your toy.

#### Warnings

(hot or cold)

DO NOT use silicone-based lube with Willow™.
DO NOT wash Willow™ in the dishwasher.
DO NOT boil, bake, or microwave.
DO NOT expose to extreme temperatures