



DIGITAL ALARM CLOCK



We hereby thank you for purchasing Baldr Digital Alarm Clock. We design and manufacture the item using innovative components and techniques to enable the perfect display of temperature and humidity in one device. Please read the instructions carefully and get familiar with the functions properly before usage.

Powered by: 2 x AA Batteries (Not included)


Product Overview

Front View



- 1. Current Time
- Low Battery Indicator
 Indoor temperature
- 2. Calendar
- 3. Weekday
- 4. Alarm 7. Indoor humidity


Back View



1. Alarm 2.Set 3.Down

4.Up 5.ON/OFF

Top View



1. Snooze/Light

Features

- 1. Time in 12/24H
- 2. Built-in Calendar and Weekday
- 3. Alarm with Snooze Function
- 4. Indoor Temperature and Humidity
- 5. Backlight
- 6. Power cut memory function
- 7. Low battery indicator

Package Content

Following contents are included in the package:

1xDigital Alarm Clock

1xUser Manual

Getting Started

- 1. Remove the battery compartment cover.
- 2. Insert 2x AA batteries matching the polarity (+and-)

Power Cut Memory Function

When the power is cut off, re-load the batteries (2 x AA) into the battery compartment within 30 seconds, the preset time will be memorized. Users don't have to reset time.

Time Setting

- Press and hold SET button for 2 seconds to enter time setting mode.
 The setting digits will be flashing.
- Press ▼ or ▲ button to set desired values .
- 3. Press and hold ▼ or ▲ button to fast advance the values.
- Press SET button to confirm the setting item and the next item to be set will be flashing.
- 5. The setting sequence is :Hour \rightarrow Minute \rightarrow Year \rightarrow Month \rightarrow Date \rightarrow Exit
- 6. Press SET button to confirm the setting.

NOTE: If there is no operation in 20 seconds, it will exit automatically. There would be AM/PM indicator while setting.

Press ▲ button to alternate between 12/24H format.

Alarm Setting

- 1. Press () button to check alarm time.
- 2. Press and hold (1) to enter alarm setting mode.
- 3. The setting item will be flashing.
- Press ▼ or ▲ button to set desired values .
- 5. Press and hold ▼ or ▲ button to fast advance the values.
- 6. The setting sequence is Hour \rightarrow Minute.
- 7. Press (5) button to confirm the setting.
- 8. To activate the alarm, press the ON/OFF button. If the alarm is activated, the alarm symbol 😭 appears on the LCD.

NOTE: When alarm time is up, it rings for 2 minutes.

Snooze Function

- When the alarm sounds ,press SNOOZE/LIGHT button to have 5 minutes' snooze time. The alarm symbol will be flashing and the alarm will sound again in 5 minutes .The snooze function has no limit and will repeat infinitely.
- 2. When the alarm sounds, press any other button except SNOOZE/LIGHT button and ON/OFF button to stop the alarm. The alarm symbol will stay on the screen and the alarm will be activated again the next day.
- To cancel the alarm, press the ON/OFF button. The alarm symbol **xwill be disappeared.

Temperature&Humidity

- 1. Indoor temperature range :-10°C to 50°C
- 2. Indoor Humidity range: 10%RH-99%RH

Backlight

Press SNOOZE/LIGHT button to turn on the backlight lasting for 10 seconds.

Precautions

Do not clean any part of the product with benzene, thinner or other solvent chemicals. When necessary, clean with a soft cloth.

Never immerse the product in water. This will damage the product.

Do not subject the product to extreme force, shock, or fluctuations in temperature or humidity.

Do not tamper with the internal components.

Do not mix new and old batteries or batteries of different types.

Do not mix alkaline, standard or rechargeable batteries with this product.

Remove the batteries if storing this product for a long period of time.

Do not dispose of this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

Warranty

BALDR provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

Warranty service can only be performed by our authorized service center. The original dated bill of sale must be presented upon request as proof of purchase to us, or our authorized service center.

The warranty covers all defects in material and workmanship with the following specified exceptions:(1) damage caused by accident, unreasonable use or neglect (including the lack or reasonable and necessary maintenance); (2) damage occurring during shipment (claims must be presented to the carrier); (3) damage to, or deterioration of any accessory or decorative surface;(4) damage resulting from failure to follow instructions contained in your owner's manual.

This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

To receive warranty service, the purchaser must contact with BALDR nominated service center for the problem determination and service procedure.

Thank you for your choice of BALDR products!

