
size: 350x80mm







TECHNICAL DATA

Watering Frequency	1/2/3/4h1week
Watering Duration	1/2/3/555Min
Max working pressure	8Bar(120PSI)
Working temperature	3°C-50°C(38°F-120°F)
Waterproof	IP54
Max flowing	35L/Min
Battery	3*AAA Alkaline Batteries
Battery life	Approx.1 year

WARNINGS


- Low Battery: The timer will stop working and the LED indicator (OFF) flashes red when battery power is low
- · Do not expose timer to frost
- Only use clear fresh cold water
- Remove and store the timer in a dry place during the winter.
- Replace all batteries at the same time and reset the parameters.

BATTERY INSTALLATION

You better use Alkaline batteries - alternatives will result in incorrect operation.

Unscrew the controller by hand form the housing of water timer, remove the cap of the battery compartment positioned on the back side of the cover, being sure that the battery compartment is clean.


Insert 3*1.5V AAA alkaline batteries(not included) in the battery compartment.(Warning:Make sure to follow the right polarity as indicated in the compartment.)



Close properly the battery compart and replace the front cover, making sure correct position of the cable to avoid compromising their integrity and functionality of the unit control. After power-on, all LED lights turn on for 1 second and then go out. After the light is off, follow-up operation can be carried out.


TIMER INSTALLATION

Screw sleeve nut of the water timer on to the outdoor hose faucet and tighten firmly to avoid leaks.




Watering time

- 1min 15min
- 2min 20min
- 3min 25min
- 5min 30min
- 8min 40min
- 10min 55min



Frequency


- 1Hour 8Hour
- 2Hour 12Hour
- 3Hour 24Hour
- 4Hour 48Hour
- 5Hour 72Hour
- 6Hour 1 Week



SET WATERING DURATION

Press the setting button continuously, and the blue LED starts to move clockwise. You can select the specified watering Duration.


For example, the following figure shows 10 minutes of watering duration



SET WATERING FREQUENCY

After setting the watering duration, wait for 4 seconds, the LED light will switch to the "1hour" position of the inner ring, and begin to set the watering frequency. The user can press the "Setting" key continuously to select the watering frequency.

For example, the following figure shows watering frequency is every 12 hours




START WATERING

After setting the watering frequency, wait for 4 seconds, the LED light will jump to "ON", and watering will start.

During watering, the "ON" light, "HOW LONG" light and "HOW OFTEN" light will flash at the same time every 4 seconds until the end of watering

Example: The picture below shows watering for 20 minutes every 6 hours.



STOP WATERING

Under the status of the blue LED, press the "Setting" key to "OFF" continuously, the watering program will be closed.

THER

- Press the "Settings" button once to wake up the LED and view the program
- Blue LED light indicates watering duration
- Green LED indicates watering frequency

MANUAL WATERING

Hold "Setting button" for 3 seconds, the indicator light will switch to "ON" position and start manual watering.

If there is no operation, manual watering will not stop.

RESET

In any case, press setting button continuously to reset watering schedule.

Pressing setting button unitl the OFF indicator lights up in red. And the red indicator will flash 4 times, then all the indicator will lights up and all settings will be erased.