

GECKO INSECT KILLER

DO NOT USE WITH WET HANDS OR IN WET/DAMP SITUATIONS

- When not in use or before cleaning, always disconnect the appliance from the mains supply.
- Ensure collection tray is empty, clean, and dry and the unit is used away from other light sources.
- Keep out of reach of small children.
- Plug in to power supply to operate, and always allow adequate ventilation around the unit or it will over heat.
- Cleaning: Remove bottom tray by twisting sideways and empty. Do not use metal objects or stick fingers through outer casing. Do not immerse in water or use harsh solvents to clean the plastic.