



Main Event Hire are  
contactable 24/7 by email at  
[info@maineventhire.com.au](mailto:info@maineventhire.com.au)

## **SMOKE MACHINE INSTRUCTIONS**

- SMOKE MACHINE WILL TAKE APPROXIMATLY **2-3 MINUTES TO WARM UP**. During the warm up period the red lights will be flashing.
- When ready the red lights will stay illuminated.
- To activate smoke, push the red light (it is a switch) on top of the smoke machine, or push the switch on the remote control.
- The smoke machine is provided full with smoke machine fluid.