



# SF007 Solar Pitcher Cascade Instructions

By All Solar Central

[www.allsolarcentral.com](http://www.allsolarcentral.com)

Thank you from the entire ASC family for purchasing an ASC solar product! Please read this entire booklet before assembly.

## Package contents:

### **Fountain:**

- 1 x Pitcher Cascade
- 1 x Access Panel Cover
- 1 x LED Light

### **Solar Water Pump Kit:**


- 1 x Water Pump with 16 ft. Cable
- 1 x Set of Fountain Nozzles
- 1 x Solar Panel with Battery
- 1 x Solar Panel Bracket
- 1 x Extension Tube
- 1 x Ground Spike

**Notes:** If there is any damage to the pitcher or missing parts, please contact us at 1-626-582-8898 or [www.allsolarcentral.com/contactus](http://www.allsolarcentral.com/contactus)



## **FOUNTAIN ASSEMBLY:**

1. Carefully remove all components from the box.





2. The pump and light cables will exit out from the access panel on the rear of the pitcher and connect to the solar panel. (Please refer to the Solar Water Pump Kit Instructions)



3. Fill the barrel with water so the pump is completely submersed. Note: In order to reduce mineral deposits and bacteria build-up, it is recommend using distilled water.

**SOLAR PUMP KIT ASSEMBLY:**

Please refer to Solar Water Pump Kit Instructions.

Please visit [www.allsolarcentral.com](http://www.allsolarcentral.com) for more product detail and offers.

