



# SF008 Solar Log & Bucket Fountain Instructions

By All Solar Central

[www.allsolarcentral.com](http://www.allsolarcentral.com)

Thank you from the entire ASC family for purchasing an ASC solar product! Please read this entire booklet before assembly.

## Package contents:

### Fountain:


- 1 x Top Bucket
- 1 x Logs and Urns
- 1 x Door Cover
- 1 x LED Light

### Solar Water Pump Kit:

- 1 x Water Pump with 16 ft. Cable
- 1 x Set of Fountain Nozzles
- 1 x Solar Panel with Battery
- 1 x Solar Panel Bracket
- 1 x Extension Tube
- 1 x Ground Spike



**Notes:** If there is any damage to the fountain or missing parts, please contact us at 1-626-582-8898 or [www.allsolarcentral.com/contactus](http://www.allsolarcentral.com/contactus)

## FOUNTAIN ASSEMBLY:



1. Attach the bucket to the tallest log. Next, feed the flexible hose through the hole into reservoir located in the log. The pump is ready to be connected. Attach the bird onto the second tallest log.

2. Attach the pump to the hose from the access panel located on the backside of the logs. Slide the pump and LED light cables through the hole of the rear access panel.



3. Fill the reservoir with water so the pump is completely submersed. **Note:** In order to reduce mineral deposits and bacteria build-up, it is recommend using distilled water.

#### **SOLAR PUMP KIT ASSEMBLY:**

Please refer to Solar Water Pump Kit Instructions.

Please visit [www.allsolarcentral.com](http://www.allsolarcentral.com) for more product detail and offers.

