



TRAVELER  
GUITAR

# User Guide

## THANK YOU FOR PURCHASING A TRAVELER GUITAR REDLANDS CONCERT!

Traveler Guitar is the industry's leading manufacturer of full-scale, travel-sized instruments. Most travel guitars sacrifice playability for portability—but at Traveler Guitar, we believe players need both. Since 1992, we have designed full-scale acoustic and electric travel guitars, offering a wide variety of solutions for players on the go.

The Traveler Guitar Redlands Concert you hold in your hands represents a revolution in travel guitar design—an acoustic guitar that features advanced built-in electronics. Its unique compact design makes it small enough to fit in an airline overhead compartment, yet full featured enough to perform on.

Join our community on Instagram and Facebook where we routinely share images of our customers with their Traveler Guitars! Be sure to tag us and use hashtag #travelerguitar when posting.



@travelerguitar



@travelerguitar

## UNPACKING YOUR GUITAR

If your guitar is factory packed it may be wrapped in a white, temperature insulating bag. This bag can be discarded.


## INCLUDED ACCESSORIES

Gig-Bag, truss rod wrench



travelerguitar.com

# ON-BOARD ELECTRONICS



## USING THE ELECTRONICS:

The preamp features standard volume, treble, middle, bass and presence controls. Be sure to unplug all cables from your guitar when not in use to save battery life.


## USING THE TUNER:

Push the Tuner button to engage the electronic tuner (this mutes the signal going to the the 1/4" output.) Play a single open string and the note name will appear on the LCD display. The screen shows a small meter which displays the string's tune. When pointing toward the left, the string is too low in pitch. When pointing toward the right, the string is too high in pitch. When pointing directly in the middle, the screen turns green and the string is in tune. The tuner works when the guitar is unplugged.

## CHANGING THE BATTERY:

The "BATT LO" indicator will light when it's time to replace the batteries. The battery access port is next to the output jack for the guitar. Install a fresh 9 volt battery, paying attention to the +/- orientation.

# STRINGING AND TUNING



## INSTALLING STRINGS:

The Redlands Concert is factory equipped with D'Addario EXP-16. If you choose to use a different gauge of strings, a truss rod adjustment may be necessary.

1. Loosen existing strings.
2. Remove strings from tuning machines by unwrapping them.
3. Remove bridge pins from bridge by using bridge pin puller or other tool.
4. Place new strings ball-end into bridge hole, and replace bridge pin, making sure to seat the ball-end before tightening the string.
5. Insert string into tuning machine, leaving approximately 2 1/2" of slack so the string can wrap around the tuning machine post. Bend the string to anchor it in place in order to hold the string after it is fed through the tuner.
6. Slowly tune to pitch.
7. Cut excess string.

# CLEANING, STORAGE, AND GENERAL CARE

## **CLEANING:**

Periodic cleaning and polishing will help protect your Traveler Guitar. Use a polish formulated for musical instruments and apply it according to the polish directions—or, you can wipe the guitar down with a clean, damp cloth followed quickly by a clean, dry cloth. To clean residue off the fingerboard, you can use extra-fine steel wool to rub up and down the length of the fingerboard over the top of the frets. Never use furniture polish on the guitar, as you may damage the finish.

## **STORAGE:**

When not in use, your Traveler Guitar should be stored in its included gig bag to protect it from exposure to the elements. Protect your guitar from extreme temperatures and changes in humidity. Never leave your Traveler Guitar in a closed vehicle or any other location where the guitar will be exposed to extreme heat. If you live in a dry climate, you may want to use a guitar humidifier.

## **ADJUSTMENTS:**

We recommend leaving complicated operations (such as truss rod adjustments) to a trained guitar technician. Improper truss rod adjustments may damage your guitar and void your warranty.

# "BUMPER TO BUMPER" LIMITED LIFETIME WARRANTY

Each Traveler Guitar instrument is warranted to be free from defects in materials and workmanship for as long as it is owned by the original retail purchaser except strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces, which are warranted for a period of three (3) years from the date of the original purchase. The warranty is only eligible to the original owner, and the guitar must have been purchased from an authorized Traveler Guitar dealer.

Traveler Guitar will replace or repair, at its discretion, any Traveler Guitar instrument or part thereof, which is found by Traveler Guitar to be defective. Traveler Guitar reserves the right to use original replacement materials or materials of similar design at the time of the repair.

To become eligible for warranty service, the original purchaser must:

1. Submit a completed warranty card or online registration form to Traveler Guitar.
2. Contact Traveler Guitar to obtain a return authorization code before returning any instrument for service.
3. Provide proof of purchase with all requests for warranty service (original receipt.)
4. Be responsible for all freight and transportation to and from Traveler Guitar's facility in Redlands, CA.

The Traveler Guitar Warranty does not cover:

1. Instruments that have been altered or modified in any way, including altered or removed serial numbers.
2. Instruments that have been subjected to extreme temperature or humidity, chemicals, synthetic materials or other abnormal conditions.
3. Wear, discoloration or marks on the finish, metal plating or wood grain of the guitar.
4. Setups, adjustments, tonal characteristics or routine maintenance of any kind.
5. Instruments that have been damaged due to misuse or neglect.
6. Normal wear and tear to hardware including: strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces. Please contact us first to resolve any warranty issues.

## WARRANTY INQUIRIES

Traveler Guitar  
ATTN: Warranty Department  
440 Business Center Court  
Redlands, CA 92373 USA  
(909) 307-2626  
travel@travelerguitar.com