



TRAVELER
GUITAR

User Guide

THANK YOU FOR PURCHASING A TRAVELER GUITAR SPEEDSTER!

Traveler Guitar is the industry's leading manufacturer of full-scale, travel-sized instruments. Most travel guitars sacrifice playability for portability—but at Traveler Guitar, we believe players need both. Since 1992, we have designed full-scale acoustic and electric travel guitars, offering a wide variety of solutions for players on the go.

The Speedster Traveler Guitar you hold in your hands represents a revolution in travel guitar design—an electric guitar that can be played anywhere. Its unique design makes it compact for travel and small enough to fit in an airline overhead compartment.

Join the community on our Photo Lounge by sending us images of you and your Traveler Guitar in exotic locations, or follow us on Facebook for more up-to-date info.

UNPACKING YOUR GUITAR

If your guitar is factory packed it may be wrapped in a white, temperature insulating bag. This bag can be discarded.

INCLUDED ACCESSORIES

Gig-Bag, truss rod wrench, and allen wrench for removing knobs




travelerguitar.com

CONSTRUCTION & SETUP

CONSTRUCTION:

The Speedster comes equipped with a standard pickup and volume and tone controls. It features an arm support for comfortable playing which is removable for transportation. The guitar and bag are only 30" long and easily fit in overhead airline compartments.

The in-body tuning system uses standard tuning machines mounted in the guitar's body to facilitate the use of standard guitar strings. The guitar has many standard features such as an adjustable truss rod, an adjustable tune-o-matic style bridge and standard 1/4" output.




ON-BOARD ELECTRONICS

USING THE ELECTRONICS:


The Speedster features a standard pickup with volume and tone knobs. The electronics are passive, and require no batteries to operate. A standard 1/4" output jack can be used to plug the guitar into an amplifier of your choice.

SETUP:


Your new Traveler Guitar Speedster will arrive with the armrest in the gig bag pocket. To prepare your guitar for play, place arm-rest in playing position. A stabilizing pin and thumb screw hold the armrest in place. Tighten the thumb screw only finger tight. (Over-tightening can dent wood or damage threads).



STRINGING AND TUNING STREAMLINE SYSTEMS



Back



Front

INSTALLING STRINGS:

The Speedster uses standard ball-end strings. (Factory installed D'Addario EXL-110.) No special tools are required for string changes.

The tuners on your Traveler Guitar operate just like the tuners on a standard guitar. Do not to remove all the strings at once. We recommend changing the strings three at a time, since some of the components are held in place by string tension. First remove the old E, A, and D strings, and then install three new strings in their places. Repeat this process on the G, B, and high E strings.

To change, thread the string through the correct hole in the end cap and wrap the string around the roller to the proper tuner hole. Leave approximately 2 . inches of slack in the string to allow 3 to 4 wraps on the tuner. Bend the string to anchor it in place in order to hold the string after it is

TUNING:

Hold the guitar in playing position and tune the strings as normal. Tuning the tuning machine in a clockwise motion raises the pitch.

CLEANING, STORAGE, AND GENERAL CARE

CLEANING:

Periodic cleaning and polishing will help protect your Traveler Guitar. Use a polish formulated for musical instruments and apply it according to the polish directions—or, you can wipe the guitar down with a clean, damp cloth followed quickly by a clean, dry cloth. To clean residue off the fingerboard, you can use extra-fine steel wool to rub up and down the length of the fingerboard over the top of the frets. Never use furniture polish on the guitar, as you may damage the finish.

STORAGE:

When not in use, your Traveler Guitar should be stored in its included gig bag to protect it from exposure to the elements. Protect your guitar from extreme temperatures and changes in humidity. Never leave your Traveler Guitar in a closed vehicle or any other location where the guitar will be exposed to extreme heat. If you live in a dry climate, you may want to use a guitar humidifier.

ADJUSTMENTS:

We recommend leaving complicated operations (such as truss rod adjustments) to a trained guitar technician. Improper truss rod adjustments may damage your guitar and void your warranty.

HANG STRAP:

The leather hang strap attached to your guitar's endcap was designed to aid in-store display, but it can also be used to hang your guitar from a wall mount or stand. Be sure your guitar is secure before walking away from it. If you wish, you can remove the strap by clipping the plastic tie with wire cutters. Be careful not to scratch the finish on the neck or endcap.

"BUMPER TO BUMPER" LIMITED LIFETIME WARRANTY

Each Traveler Guitar instrument is warranted to be free from defects in materials and workmanship for as long as it is owned by the original retail purchaser except strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces, which are warranted for a period of three (3) years from the date of the original purchase. The warranty is only eligible to the original owner, and the guitar must have been purchased from an authorized Traveler Guitar dealer.

Traveler Guitar will replace or repair, at its discretion, any Traveler Guitar instrument or part thereof, which is found by Traveler Guitar to be defective. Traveler Guitar reserves the right to use original replacement materials or materials of similar design at the time of the repair.

To become eligible for warranty service, the original purchaser must:

1. Submit a completed warranty card or [online registration](#) form to Traveler Guitar.
2. Contact Traveler Guitar to obtain a Return Authorization Code before returning any instrument for service.
3. Provide proof of purchase with all requests for warranty service (original receipt.)
4. Be responsible for all freight and transportation to and from Traveler Guitar's facility in Redlands, CA.

The Traveler Guitar Warranty does not cover:

1. Instruments that have been altered or modified in any way, including altered or removed serial numbers.
2. Instruments that have been subjected to extreme temperature or humidity, chemicals, synthetic materials or other abnormal conditions.
3. Wear, discoloration or marks on the finish, metal plating or wood grain of the guitar.
4. Setups, adjustments, tonal characteristics or routine maintenance of any kind.
5. Instruments that have been damaged due to misuse or neglect.
6. Normal wear and tear to hardware including: strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces.

Please contact us first to resolve any warranty issues.

Warranty Questions:

Traveler Guitar ATTN: Warranty Information
440 Business Center Court
Redlands, CA 92373 USA
travel@travelerguitar.com