



**TRAVELER**  
**GUITAR**

# STRINGING AND TUNING

## **Guitars with In-Body™ Tuning:**

The tuners operate and are set up like the tuners on a standard guitar. We recommend that you change the strings one at a time, starting with the low E.

To change, thread the string through the correct hole in the endcap and wrap the string around the roller to the proper tuner hole. Leave approximately 2 ½ inches of slack in the string to allow 3 to 4 wraps on the tuner. Bend the string to anchor it in place in order to hold the string after it is fed through the tuner. Over or under wrapping the string around the tuner may cause tuning problems.

## **Guitars with Streamline™ Tuning:**

Streamline equipped guitars use standard, ball-end strings. (Factory installed D'Addario EXP-16.) Only a single allen wrench (included) is required to change strings. We also recommend that you change the strings in pairs due to the string clamps.

First, loosen existing string by loosening the Knurled Tuning Knob. This allows you to access the ball-end cavity of the String Sled. Remove the old string then place the ball end of the new string in the cavity. Tighten the knurled tuning knob just enough that the ball end will not fall out of the sled. Now on the endcap loosen and remove the string clamp holding the old strings. Loosen the individual string locker. The old string can be pulled out and the new string can be fed through the hole in the endcap. Pull the string as tight as possible. Now tighten the individual string locker. Re-install the string clamp and tighten it. Any excess string can now be cut off. Tune to pitch.

Visit our website for instructional videos  
[travelerguitar.com](http://travelerguitar.com)

# FACTORY EQUIPPED STRINGS

Your Traveler Guitar is factory equipped with the following strings:

## **Traveler Acoustic (Streamline)**

D'Addario® EXP16 Coated Light Gauge Acoustic Strings, .012-.053

## **Acoustic**

D'Addario® EJ15 Extra Light Gauge Acoustic Strings, .010-.047

## **Electric**

D'Addario® EXL110 Regular Light Gauge Electric Strings, .010-.046

## **Nylon**

D'Addario® Pro-Arte EJ45 Normal Tension Nylon Strings, .028-.043

## **Bass**

D'Addario® EXL165 Regular Light Gauge Bass Strings, .045-.105

## **“BUMPER TO BUMPER” LIMITED LIFETIME WARRANTY**

Each Traveler Guitar instrument is warranted to be free from defects in materials and workmanship for as long as it is owned by the original retail purchaser except strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces, which are warranted for a period of three (3) years from the date of the original purchase. The warranty is only eligible to the original owner, and the guitar must have been purchased from an authorized Traveler Guitar dealer.

Traveler Guitar will replace or repair, at its discretion, any Traveler Guitar instrument or part thereof, which is found by Traveler Guitar to be defective. Traveler Guitar reserves the right to use original replacement materials or materials of similar design at the time of the repair.

# **“BUMPER TO BUMPER” LIMITED LIFETIME WARRANTY**

## **To become eligible for warranty service, the original purchaser must:**

1. Submit a completed warranty card or online registration form to Traveler Guitar.
2. Contact Traveler Guitar to obtain a Return Authorization Code before returning any instrument for service.
3. Provide proof of purchase with all requests for warranty service (original receipt.)
4. Be responsible for all freight and transportation to and from Traveler Guitar’s facility in Redlands, CA.

## **The Traveler Guitar Warranty does not cover:**

1. Instruments that have been altered or modified in any way, including altered or removed serial numbers.
2. Instruments that have been subjected to extreme temperature or humidity, chemicals, synthetic materials or other abnormal conditions.
3. Wear, discoloration or marks on the finish, metal plating or wood grain of the guitar.
4. Setups, adjustments, tonal characteristics or routine maintenance of any kind.
5. Instruments that have been damaged due to misuse or neglect. Normal wear and tear to hardware including: strings, tuning machines, frets, switches, electronic components, jacks, pickguards, and plated surfaces.

**Please contact us first to resolve any warranty issues.**

[travel@travelerguitar.com](mailto:travel@travelerguitar.com)

or

Traveler Guitar  
ATTN: Warranty Information  
440 Business Center Court  
Redlands, CA 92373 USA