

Fore-aft seat adjust handle replacement



Step 1

Install the stud and nut, hand tighten the stud.



Step 3

Using a 5 mm wrench, tighten the screw with washer and rubber cap. Be sure to use Loctite 242 on the screw threads.



Step 2

Install the handle on to the tightened stud. Ensure that when the seat adjustment is tight, the handle points towards the rear as shown.



*For support please contact the
Keiser service department*

KEISER

2470 S CHERRY AVE • FRESNO CA 93706

TOLL FREE 1.800.888.7009 • PHONE
559.256.8000

FAX 559.256.8100 • www.keiser.com

E-mail: service@keiser.com