



ATTENTION

DO NOT USE "POPCORN" OR "CONVECTION" SETTINGS

The "POPCORN" button on your microwave does not adjust for various Serving Sizes and Microwave Wattages. Modern microwaves are high powered and your popcorn may burn if you press "POPCORN" button and leave it unattended. Also do not use the "CONVECTION" setting because it will circulate hot air rapidly and will produce unexpected results.

DO NOT POP WITH BUTTER

Do not pop the kernels with Butter inside your Colonel Popper. Butter has a low smoke point so it burns easily. If you like the taste of Butter, melt it separately then pour onto the finished popcorn and mix.

PRO TIP: When the Grab Handles have cooled, you can grip them to toss your popcorn and mix with the melted Butter and additional Seasoning!

LOWER YOUR POWER LEVEL

Search online for your microwave's wattage. Lower the Power Level according to our reference guide (on reverse side). Disclaimer: We are not responsible for burnt popcorn or misuse of Colonel Popper.

OIL IS NOT REQUIRED FOR POPPING

Colonel Popper was designed to pop without any Oil. Using Oil is purely a taste preference and for seasoning to stick onto the kernels. The optimal temperature for kernels to pop is 365 F. So if you prefer Oil, it must have a high smoke point such as Ghee, Avocado Oil, Canola Oil, Sunflower Oil, Soybean Oil, Peanut Oil, Olive Oil, Popcorn Popping Oil, and Butter Flavored Coconut Oil. Oil Spray actually works even better since there is less Oil used to evenly coat the kernels.

HOW TO KNOW WHEN YOUR POPCORN IS DONE

Microwaves vary in wattages and sizes. Do not leave your microwave unattended while popping. Listen for a 2-3 second pause between pops and this will indicate that your popcorn is done. After your Heating Time and Power Level are established, you will be making fresh, crisp, and delicious popcorn consistently each time.

100% BPA FREE SILICONE - LFGB CERTIFIED AND PASSES PINCH TEST

Colonel Popper Silicone is certified for German LFGB Food-Grade Safety and is 3rd Party Accredited Independent Lab Tested to be BPA Free, Phthalate Free, Lead Free. We are based in U.S.A. and care about customer safety.

CARE INSTRUCTIONS

Thoroughly clean before first use by Hand Wash or in the Dishwasher using Warm Water and Dish Soap. The Clear Lid may naturally darken over time which is normal and will not affect the performance. We have Deep Clean Instructions on our website using 100% Natural Ingredients at www.shopcolonelpopper.com.

NEED HELP? Our POP-LINE is open! HELP@SHOPCOLONELPOPPER.COM

1

POP UP BOWL

Pop up the Bowl and remove Lid.



Disclaimer: We are not responsible for burnt popcorn or misuse of Colonel Popper.

Required: Search online for your microwave's wattage. Lower the Power Level according to the wattage and adhere to the Heating Times referenced below.

2

DROP IN KERNELS

Pour kernels into the Bowl with measuring cup, then gently drop Lid.



Check that the Lid sits halfway into the bowl evenly with no gaps for steam to escape.

Do not pop with Butter! Oil or Oil Spray are optional and use between 1/2 to 1 TBSP.

3

HEAT IN MICROWAVE

Place the Bowl in the microwave and choose the correct Power Level and Heating Time. Listen for a 2-3 second pause between pops then stop microwave. Add another 30 seconds if popcorn is not done popping.

**3-4 MIN**

Do not leave microwave unattended. Chart below is a guide only, and it may take a few tries to establish your optimal heating time.

4

EAT AS HEALTHY SNACK

When the Grab Handles have cooled, remove from microwave and slowly lift the lid. Enjoy!



MICROWAVE	700 W	800 W	900 W	1000 W	1100 W	1200 W
POWER LEVEL	10 (HIGH)	10 (HIGH)	9	8	7	6
1/4 CUP (1 Serving)	4:00 min	3:45 min	3:45 min	3:30 min	3:15 min	3:00 min
1/3 CUP (2-3 Servings)	4:15 min	4:00 min	4:00 min	3:45 min	3:30 min	3:15 min
1/2 CUP (3-4 Servings)	4:30 min	4:15 min	4:15 min	4:00 min	3:45 min	3:30 min