

KAMBROOK



Suits all KCP150 models

Important

Please retain your instruction book for future use.

In the event that you need some assistance with your Kambrook appliance, please contact our Customer Service Department on 1300 139 798 (Australia) or 0800 273 845 (New Zealand). Alternatively, visit us on our website at www.kambrook.com.au or www.kambrook.co.nz

Contents

Kambrook Recommends Safety First	p4
Your Kambrook Citrus Press	p6
Operating Instructions	p7
Care, Cleaning and Storage	p10

IMPORTANT: Please retain your instruction book for future use.

At Kambrook, we believe that safe performance is the first priority in any consumer product, so that you, our valued customer can confidently use and trust our products. We ask that any electrical appliance that you use be operated in a sensible fashion with due care and attention placed on the following important operating instructions.

Important Safeguards For Your Kambrook Citrus Press

- Carefully read all instructions before operating the citrus press for the first time and save for future reference.
- Remove and safely discard any packaging material and promotional labels before using the citrus press for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this citrus press.
- When unpacking the citrus press, check to see you have received all the items listed in the parts list, before discarding the packaging.
- Always ensure the citrus press is properly assembled before use. Follow the instructions provided in this book.
- Always ensure the citrus press is properly and correctly assembled before operating.
- Always operate the citrus press on a stable and heat resistant surface.
- Do not place the citrus press near the edge of a bench or table during operation. Ensure that the surface is level, clean and free of water and other substances.
- Do not place the citrus press on or near a hot gas or electric burner, or where it could touch a heated oven.
- Use caution when operating the citrus press – do not place hands or fingers near moving or rotating parts.
- Ensure that the power source to be used is the same as the voltage requirements of the citrus press.
- Do not immerse the motor base, cord or plug in water or any other liquid.
- Always turn the power off at the power point and then unplug the power cord, before removing the strainer, cones and reservoir for cleaning.
- Always switch off at the power outlet and then unplug when not in use, before adding or removing parts, before cleaning and when storing.
- Always turn the power off at the power outlet and then remove the plug before disassembling the unit.
- Do not leave the citrus press unattended when in use.
- Keep the citrus press clean. Follow the cleaning instructions provided in the book.

Important Safeguards For All Electrical Appliances

- Fully unwind the power cord before use.
- Connect only to a 230V or 240V power outlet.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- To protect against electric shock, do not immerse the power cord, power plug or appliance in water or any other liquid.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to regularly inspect the appliance regularly. To avoid a hazard, do not use the appliance if power cord, power plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Kambrook service centre for examination and / or repair.
- Any maintenance other than cleaning should be performed at an authorised Kambrook Service Centre.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. **Misuse may cause injury.**
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- Always turn the appliance to the OFF position, switch off at the power outlet and unplug at the power outlet when the appliance is not in use.
- Before cleaning, always turn the appliance to the OFF position, switch off at the power outlet, unplug at the power outlet and remove the power cord, if detachable, from the appliance and allow all parts to cool.
- Do not place this appliance on or near a heat source, such as hot plate, oven or heaters.
- Position the appliance at a minimum distance of 20cm away from walls, curtains and other heat or steam sensitive materials and provide adequate space above and on all sides for air circulation.

Your Kambrook Citrus Press

1. Transparent lid for storing.
2. Large juicing cone – attaches to the small juicing cone for extracting juice from large citrus fruits, such as grapefruit and oranges.
3. Small juicing cone with drive shaft connection – perfect for juicing smaller citrus fruits, such as lemons and limes.
4. Removable stainless steel strainer - helps to strain pulp and seeds as the juice flows into the reservoir or spout.
5. Juice reservoir – collects juice (up to 350ml) if the spout is in the non-flow position.
6. Sealable spout to control the flow of juice – press down to open the spout and allow juice to flow freely into a waiting vessel (not included). Push up for a non-flow position to hold the juice in the reservoir.
7. Drive shaft – attaches to the motor base to automatically rotate the juicing cone in a counter-clockwise direction when downward pressure is applied during juicing.
8. Motor base with stainless steel housing for easy cleaning.

Not Shown

- Cord
- Cord wrap
- Non-slip suction feet for stability



Operating Instructions

Before First Use

Before using the citrus press for the first time, rinse the cones, strainer, juice reservoir and transparent storage lid with warm water and a few drops of washing-up liquid. Dry all parts thoroughly before assembling the citrus press.



WARNING: The motor base must not be immersed in water or other liquids or held under running water as this could give you an electric shock. Wipe the motor base with a damp cloth.

Assembling

1. Place the motor base on a flat, even surface.
2. Attach the drive shaft to the motor base.
3. Place the juice reservoir and then the strainer onto the drive shaft.
4. Attach the large juicing cone to the small cone until you hear a click to indicate the large cone is securely connected and then place onto the drive shaft.
5. When storing, place the transparent lid on top of the citrus press when assembled.


NOTE: Only the small juicing cone has the drive shaft connection and therefore must be connected to the drive shaft to operate the citrus press. Attach the large citrus cone to the small cone for larger fruit.



Operating Instructions continued

1. Stand the citrus press on a dry, even surface that is easy to clean.
2. Fully unwind the power cord from the cord storage compartment under the citrus press. Make sure that the cord is correctly positioned in the cord guide to prevent the citrus press from wobbling.
3. Connect the power plug to a 230-240V power outlet and turn the power on.
4. Remove the transparent storage lid.
5. Fit the appropriate citrus cone onto the drive shaft to suit the citrus you are using (*see suggested cone size table*).
9. Once you reduce the pressure on the cone, the citrus press will automatically stop.
10. The juice reservoir has a sealable spout to stop the juice flow temporarily. To stop the juice flow, push the spout upwards (Fig. 2).

NOTE: If you are using the large cone, attach it securely on top of the small cone before placing it onto the drive shaft.



6. Place a glass or container (not included) under the spout to collect the juice from the spout.
7. To reduce pulp and seeds from the juice, ensure the strainer is in place prior to juicing. Select your choice of citrus fruit, wash and then cut in half.
8. Pressing down, place the cut half of the citrus fruit to the top of the cone to automatically activate the citrus press. The cone will start to turn in a counter-clockwise direction (Fig. 1) and juice will begin to flow.



11. To enable the juice to flow through the spout, press the spout downwards and place a glass under the spout to catch the juice (Fig. 3).



NOTE: If the spout is in a non-flow position, the juice will collect in the juice reservoir. Be mindful not to overfill the reservoir. If the spout is in a flow position, the juice will flow from the spout.

NOTE: To maximise the quantity of juice extracted from the fruit, press the fruit half onto the cone several times.

NOTE: The strainer should be emptied when full with pulp and seeds. The strainer can be emptied during juicing by turning the juicer OFF at the power outlet and carefully removing the juicing cone and strainer. Clean and replace strainer and juicing cone before continuing use.

Do not allow the strainer to overfill as this may prevent correct operation or damage the unit.



WARNING: Do not operate the citrus press for more than 5 seconds continuously at one time. Allow the motor to cool between use.

Suggested Cone Size Table

Fruits	Small Cone	Large Cone
Orange (Large)		✓
Orange (Small)	✓	
Lemon (Large)		✓
Lemon (Small)	✓	
Lime (Large)	✓	
Lime (Small)	✓	
Grapefruit		✓

Care, Cleaning and Storage

Before cleaning, ensure the power outlet is switched off and then remove the power plug from the power outlet.

Always clean your citrus press after each use to prevent a build-up of pulp and juice.

Cleaning

Remove the citrus cone(s), strainer, juice reservoir & drive shaft from the citrus press and clean them in warm soapy water, then rinse and dry thoroughly.

Wipe clean the motor base with a damp cloth.



WARNING: Do not immerse the motor base, cord or plug in water or any other liquid.

5. Wrap the power cord in the cord wrap area on the base of the citrus press.
6. Store on a dry and flat level surface. **Do not place anything on top of the citrus press.**



WARNING: The transparent storage lid is simply designed to sit on top of the citrus press to protect from dust when not in use. It does not lock onto the citrus press so all care should be taken when moving the citrus press not to accidentally dislodge the lid. Ensure you use both hands to transport the citrus press.

Recommended

It is best to rinse or wash all removable parts immediately as dried citrus pulp is difficult to remove and may stain.

Storage

To store the citrus press:

1. Ensure the power is switched off at the power outlet and then unplug power cord from the power outlet.
2. Clean and dry all the parts of the citrus press immediately after use and before storing.
3. Re-assemble the unit as per instructions in Assembling the citrus press (page 7).
4. Fit the storage lid onto the citrus press.

Kambook - Australia

Ground Floor, Suite 2, 170-180 Bourke Rd
Alexandria NSW 2015, Australia

Locked Bag 2000
Botany NSW 1455
Customer Service Line 1300 139 798
Customer Service Fax 1800 621 337

www.kambook.com.au

Kambook - New Zealand

Private Bag 94411
Botany, Manukau
Auckland 2163
New Zealand
Customer Service Line/
Spare Parts 0800 273 845
Customer Service Fax 0800 288 513

www.kambook.co.nz

KAMBROOK

Due to continual improvement in design or otherwise, the product you purchase may differ slightly from the illustration in this book. Issue A18