
## V01MKII

## INSTRUCTIONS



Designed by David Ericsson Movement: VOID VO1EL | Battery: CR2016 / 3V Water Resistant 5ATM/50M Material: Stainless Steel & Sapphire Glass Made in China

## INSTRUCTIONS

## SETTING TIME AND DATE

To display date: Press B.
To light the display: Press C.

Press A to enter setting mode using a ballpoint pen or blunt tool.

Press A again to select, seconds, hours, minutes, month and day.

Press B To adjust the flashing item.

 $^{\star}$ When setting, the flashing seconds can be reset to zero by pressing B.