

ASSEMBLY INSTRUCTION


DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS



15 min



0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14



HW-ST-02-079
(8 x 50)

x 4

2



HW-ST-07-062
(8.5x12.5x1.5)

x 4


3



HW-ST-07-054
(8.5x20x2)


x 4

4




HW-ST-18-007
(13 x 88)

x 1



A x 1

SU-SC-AS-0134



B x 4

SU-TB-LF-1474

