


SnapSights SS01 film reloading instructions



- 1) Open camera by first removing sticker. 2) Slide release downward on camera's side. 3) Open back cover.



- 4) Lift out used roll of film and take to photolab promptly for processing. 5) Take new 27 exp roll of film out of box and insert in same place where used roll was. 6) Extend film tip so that it reaches the winding spool.



- 7) Make sure holes in the film are engaged with the film counter sprocket. 8) Make sure one of the holes in the film is engaged with the tooth on winder spool.



- 9) Close back of camera and replace sticker. 10) Slide winder switch on back of camera to the left. 11) Lift up winder lever.



- 12) Advance film by **carefully** turning film winder **counter-clockwise**. 13) Stop when winder cannot advance further and check to see that the film counter is at 27. (If the counter does not advance, film is not loaded correctly: repeat step 7 - 8). 14) Slide winder switch back to the right. Place camera back into waterproof housing and start taking great underwater pictures again!