

### To Activate the WI-FI Remote Control on the X2 Camera

Download and install our INTOVA WiFi app from either the App Store (for iOS phone or tablet) or Google Play Store (for Android phone or tablet) and use your phone or tablet to remotely control the X2 for video recording or photo taking.

After downloading and installing the INTOVA app, below are the basic steps to connect to our X2 camera.

1. With a microSD card inserted into the X2, turn ON the camera. Please check to be sure that the battery power level is at least 3 bars (fully charged is best since WIFI consumes a lot of power).
2. Press and hold the MENU/OK button (the middle button on side of camera) to turn ON WiFi signal.
3. The word "Processing" in red should appear on the LCD screen.
4. The WiFi icon in the top/middle part of the LCD will turn green to indicate that the WiFi signal is ON.
5. Turn ON your smart phone or tablet that has the INTOVA WiFi app installed.
6. Tap your Settings icon to enter settings.
7. Tap WiFi to enter WiFi function.
8. Turn ON WiFi if it is OFF.
9. Look for INTOVA X2 signal and tap to connect. The password is 0123456789.
10. When signal is connected, press home button to go to home screen.
11. Tap INTOVA WiFi app icon to turn app ON.
12. Tap EDGE X2.
13. Tap CONTROLS.
14. You should now see the live view from the camera on your phone or tablet.
15. Use the controls on the app screen to remotely record videos or take photos.