



NEW IN FIRMWARE 1.50

Release 7/11/2018

1) MASTERFADER options:



The MASTERFADER now has 2 option:
ALL: the masterfader controls all intensity Channels

SELECTED: the masterfader only controls
The intensity channels from the
Selected fixtures

2) ACTIVE NAMETAGS:



When you have selected multiple lightfixtures,
You now get a shortcut to access the
fixturesettings. By tapping on the nametag
above the slider, you open all the options for
this fixture.



To return to your selection, you just close
the popup window by tapping exit in the top
right corner.

3) TOUCHSCREEN options:



You can now DISABLE or ENABLE the touchscreen ,

4) PATCH FUNCTION:



In the EDITMENU, you can now find the PATCH function to help you find a free DMX address.

For example:

I opened the EDIT menu and have selected a skypanel C1 to patch to FIXTUREBUTTON 3.



By selecting SAVE without entering a DMX Startaddress, the fixture is automatically patched to startaddres 001.



By selecting PATCH in the left top corner, You open the patchlist, now we see that 1 till 12 is red underlined. This means we have a double patch on these addresses. At the same time we see that address 19 is free.



So now when I tap on address 19, you see that the red disappears and that we get a white line starting at 19 which represents the 12channels from the skypanel in mode 1.

Then just tap EXIT to go back to EDITmenu



Now you just have to select SAVE again to patch to DMX address 19