



FIGURE DISPLAY CUBBY



Included

32 Pins




1 Top zBoard



1 Back zBoard




2 Vertical zBoards (side zBoards) 4 Vertical zBoards (middle zBoards)



1 Bottom zBoard

Important




DO NOT place unit on its side or back as it will compromise its structural integrity.

WARNING: CHOKING HAZARD
Small parts NOT for children under 3 years




- Assemble your unit on a flat even surface
- Make sure zBoard surfaces are clean and dry


- When moving your Way Basics unit, lift from the bottom
- Use indoors and in dry areas only. Do not use in the bathroom




- 1** Carefully remove the protective layer on the Vertical zBoards and Back zBoard (making sure not to remove the 3M adhesive shown in yellow).
Tip: Peel protective layer from side.




- 2** Insert pins as shown.




- 3** Align Back zBoard to holes in Bottom zBoard.



- 4** Align Vertical zBoards to holes in Bottom zBoard.



- 5** Align Top zBoard as shown and press firmly to secure unit together.



- 6** Easily expand your storage with another stacking unit. Use alignment pins to keep the units from sliding. Enjoy building possibilities!

