

CAT SCRATCHER CORNER



• Use indoors and in dry areas only. Do not use in the bathroom








WARNING: CHOKING HAZARD

Small parts NOT for children under 3 years



Assemble your unit on a flat even surface

• Make sure zBoard surfaces are clean and dry

Carefully remove the adhesive protective layer (making sure not to remove the 3M adhesive shown in yellow). Secure on the corner of a wall or couch.
Warning: The adhesive is very sticky and may cause damage on wall, paint, or furniture.



