




Electronic Lock Instructions



Your Electronic Lock is currently set with the default combination of:
1-2-3-4-1-2

OPEN:

Step 1: Twist key LEFT (counter-clockwise) to open door

- Door will spring open




INSERT BATTERY:

Step 2: Remove battery cover

- Located on the upper right interior wall

Step 3: Slide a 9V battery into battery slot



Step 4: Snap battery cover back into place



CHANGE YOUR COMBINATION:

Step 5: Press change combination button next to interior light

Step 6: Input your new 6 digit combination

- Lock will beep, click, & light will turn on

Your new combination is now installed.

IMPORTANT!

Test your new combination several times with the door open to ensure new combination is properly set before closing and locking safe.

RECORD NEW COMBINATION HERE: