







BR87 Parts Illustration - Detail E		
ITEM	P/N	DESCRIPTION
1	06687	Valve Cap
2	04052	O-ring*
3	01772	O-ring
4	06684	Sintered Filter
5	22768	Seal Spacer
6	06688	Retaining Ring
7	04051	Charge Valve
8	10180	Caution: Nitrogen Gas Under Pressure Decal
9	02494	Handle Grip
10	11432	Woodruff Key - Model BR8713201FS, BR8717201
11	01003	Valve Button - Model BR8713201FS
12	11431	Lock Pin - Model BR8713201FS, BR8717201
13	11430	Spring - Model BR8713201FS, BR8717201
14	22891	Roll Pin
15	04049	Handle
	11435	Handle - Model BR8713201FS, BR8717201
16	05465	Orifice Plug
17	04058	Spring
18	04077	Valve Spool
19	01362	O-ring*
20	04057	Bushing
21	00293	O-ring*
22	04056	Rod Wiper*
23	04055	Washer
24	04053	Trigger
	11434	Trigger - Model BR8713201FS, BR8717201
25	28322	CE Decal
26	11207	Circuit Type "D" Decal
27	58601	Sound Power Decal
28	28409	Composite Safety Decal
29	04054	O-ring*
30	04060	Accumulator Cylinder
31	04059	Accumulator Diaphragm
32	05309	Accumulator Chamber
33	05301	Backup Washer
34	05307	Rod Seal*
35	04064	Seal Retainer Washer
36	24666	Elastomeric Spacer
37	04071	Side Rod
38	05265	Flow Sleeve Housing
39	74832	STANLEY Logo Decal
40	04075	Side Rod Nut
41	11208	Hex Shank Length Decal - Model BR8717201
42	Depends on Model	Breaker Foot - See Detail F & G
43	74673	Tool Name Tag
	74666	Tool Name Tag - Model BR87120D
44	03972	Female Coupler

BR87 Parts Illustration - Detail E		
ITEM	P/N	DESCRIPTION
45	03973	Male Coupler
46	01652	Hose
47	16812	Piston
48	04054	O-ring*
49	04066	Automatic Valve Body
50	04571	Push Pin
51	07890	Roll Pin
52	04065	Automatic Valve
53	04067	Push Pin
54	04069	Flow Sleeve
55	04054	O-ring*
56	04068	Flow Sleeve Tube
57	05485	Seal Kit (Not Shown) - * In Seal Kit

Breaker Foot Assembly - Detail F					
ITEM	DESCRIPTION	QTY	MODEL		
			BR87120, BR87120D, BR87120J	BR87130, BR8713201FS	BR87320
1	Cup Seal	1	34127*		
2	Seal Insert	1	05466 (Must purchase entire foot assembly)	05467 (Must purchase entire foot assembly)	08855 (Must purchase entire foot assembly)
3	Rod Wiper	1	04074*		
4	O-ring	1	04073*		
5	Breaker Foot	1	05466 (Must purchase entire foot assembly)	05467 (Must purchase entire foot assembly)	08855 (Must purchase entire foot assembly)
6	Hex Bushing	1	05466 (Must purchase entire foot assembly)	05467 (Must purchase entire foot assembly)	08855 (Must purchase entire foot assembly)
7	Spring	1	01744		
8	Detent	1	08411		
9	Nylock Nut	1	04984		
10	Washer	2	04985		
11	Taper Sleeve	2	01269		
12	Latch	1	01837		
13	Foot Latch Bolt	1	04983		

Breaker Foot Assembly - Detail G					
ITEM	DESCRIPTION	QTY	MODEL		
			BR8713015E, BR87130E (07486)	BR87120E (07523)	BR8717201 (11638)
1	Cup Seal	1	34127*		
2	Seal Insert	1	07486 (Must purchase entire foot assembly)	07523 (Must purchase entire foot assembly)	11638 (Must purchase entire foot assembly)
3	Rod Wiper	1	04074*		
4	O-ring	1	04073*		
5	Breaker Foot	1	07486 (Must purchase entire foot assembly)	07523 (Must purchase entire foot assembly)	11638 (Must purchase entire foot assembly)
6	Hex Bushing	1	07486 (Must purchase entire foot assembly)	07523 (Must purchase entire foot assembly)	11638 (Must purchase entire foot assembly)
7	Spring	1	07514		
8	Spring	1	01744		
9	Detent	1	08411		
10	Nylock Nut	1	04984		
11	Washer	2	04985		
12	Taper Sleeve	2	01269		
13	Retaining Ring	1	07522		
14	Wear Ring	2	07516		
15	Collar Support	1	07520	07519	12013
16	Foot Latch Bolt	1	04983		
17	Latch	1	01837		