





# POWER U-BASE

(UXT) RPUB










	Parts Description	Code
1	 Tendon bolt and nut	RPBPDPT
2	 Power base Tendon	RPBPT
3	 Plastic disk with EVA pasted	RPBPPD
4	 Mast box Brass Locking nut	RPBPLN0000

# POWER M-BASE

(MXT) RPM



	Parts Description	Code
1	 MXT power base top cap with tapping screws	RPBPDPT
2	 MXT power base plastic button	RPBPBT0000
	 MXT power base button V-spring	RPBPBS0000
3	 Tendon bolt and nut	RPBPDPT
4	 Power base Tendon	RPBPT
5	 Plastic disk with EVA pasted	RPBPPD
6	 Mast box Brass Locking nut	RPBPLN000