



| RS:ONE BASE | | |
|-------------|------------------------|-----------|
| 1. | Push Pin for Adapter C | RPBPPAC |
| 2. | Tendon bolt and nut | RPBPDPT |
| 3. | Power base Tendon | RPBPT |
| 4. | RSX Lower Housing Set | RMPRSXLRH |
| 5. | Bottom washer | RMPRSXWSH |

NeilPryde do not reccommend customers replace upper or lower housings themselves as a safety precaution.

O BASE

