






# **EV-DUO-CORE(-B)**


















## INSTALLATION LEAFLET

#### DIMENSIONS







Voltage	230V~ 50Hz
Class	II
Working Temp.	40°C
Max power consumption	2.5W
Average power consumption	1.0W

CCT 6000K IP Rating IP65 Mounting Type Wall Mounted Terminal Block Wiring 0∩ min


Duration

**Battery Type** LiFePO<sub>4</sub> **Battery Capacity** 3.2V 3400mAh 12006 **Battery Code** Charging Time 16 Hours **Charger Type** Variable

#### **BATTFRY LIFF**

**SPECIFICATIONS** 

To maintain the economic life of this product it is required that the battery be discharged and recharged at least once every 6 months. The battery life can be reduced if the battery is not discharged as per the requirements of AS/NZS 2293 or an equivalent standard. Increasing the number of duration tests above that as defined in AS/NZS 2293 or an equivalent standard can have a positive effect on the battery performance as long as 12 discharge cycles per year is not exceeded. The recharging device will operate normally after removal of short circuit fault.



#### **TEST SWITCH**

Action	Function
Hold	Run in emergency mode

### STATUS CHARGE LEDS (GREEN) Indicator

maicator	Meaning
On	Battery charging
Battery test*	
2x flash	Battery full
4x flash	NTC noncharge
5x flash	Battery charge
3 x flash	Lamp failure
Off	Battery charger off/disconnected
*After emergen	cy test mode is activated via test switch

ORDERING INFORMATION				
SKU	Product code	Description		
12144 12145	EV-DUO-CORE EV-DUO-CORE-B	Duo Core Emergency Luminaire Duo Core Emergency Luminaire - Black		

#### REPLACING THE BATTERY

Access the battery by removing the gear tray. Disconnect and remove battery. Replace battery as was previously installed. Battery can be connected in one direction only, do not force. Allow a minimum 24 hours charging time before carrying out any discharge tests as per the requirements in AS/NZS 2293.

### **SAFETY WARNINGS**

- This product must only be installed by a licensed electrician.
- Before commencing installation turn off and isolate the electrical supply.
- Risk of accidental contact with live parts. do not energise with product open or disassembled.
- Mains supply and battery circuit separated by reinforced insulation.
- The only user serviceable / replaceable part is the battery pack.
- Do not attempt to service other parts of the fitting as this will void the warranty
- After installation allow the battery to charge for 24 hours before carrying out discharge testing.
- 8. As the installer, it is your responsibility to ensure you comply to all relevant building and safety codes.
- 9. The light source contained in this luminaire shall only be replaced by the manufacturer or their service agent or a similar qualified person.
- 10. The replacement of the battery is needed when they no longer meet their rated duration of operation after the corresponding recharge period.
- 11. This luminaire is intended only for mounting in locations where the plug and socket are protected from unauthorized disconnection.
- 12. All maintenance, such as battery change on this luminaire to be performed by qualified personnel only. De-energise all supplies before maintenance.