

Festoon Lighting Installation Instructions



Festoon Lighting can be dangerous if used incorrectly so please read carefully.

- Before installing, inspect the lampholders to make sure there are no breaks to the seals.
- The power plug cap at the end of the festoon must always be on and turned tightly.
- Avoid the lampholders with your fingers. If you put your finger inside the lampholder you will get a shock.
- Do not hang above bodies of water.
- You must install the festoon lamps facing down only, not up, as the water will enter if facing up.
- Festoon application is strictly to be hung in the air or surface mounted to a roof or wall.
- When installing the festoon try not to make lengths longer then 6 meters for each drop. If longer than 6 meters use cable ties or hooks.
- When installing globes, ensure they are tightened as far as possible so that the seal is created.
- If a globe dies, the festoon will still run normally. However, it is crucial to leave the blown globe still intact in the lampholder as it will keep the water out.
- When installing the bulbs, make sure the festoon is unplugged from the wall socket.
- Do not cluster bulbs together in a bunch.
- Do not exceed 1500 watts.
- These festoons are able to use LED, Incandescent, CFL and halogen lamps.
- 24v low voltage model the LED 24v systems are more ideal for long term commercial or residential
 applications. They will run at less power and if something was to go wrong 24v is 0 risk of electrocution. When
 running the 24v system you can not connect multiple runs as the driver/transformer is only able to run the
 allocated wattage purchased. However, if you tell us before purchasing, we can increase the driver and lengths.
- Custom lengths are available, please email customerservice@thelightingoutlet.com.au

Technical Speciation's

IP44 (Rated for indoor or outdoor)

240v E27

1.5 Meter Australian flex and plug included

Warranty – 2 years for the festoon string. **0 warranty for incandescent** globes, these are complimentary only. **LED** globes have a 2 year warranty, and **carbon filament** have a 1 year warranty.

Warranty does not cover incorrect installation or placement.

Dimmable – (Only when using dimmable globes) Check your wattage before purchasing the dimmer. Dimmers will have a certain load they can handle and you may be over the wattage.

Read our blog on the website link below to learn the expert guide to festoon.

thelightingoutlet.com.au/blogs/news/festoon-lighting