





PIXIE MULTI-WAY SWITCH G3 S2W/BTAS

SMART HOME - digital multi-way switch or dimming control

Application

Ideal for residential designs, commercial interior spaces requiring multiple location device control

Design Specifications

- Digital remote push button control to enable 2 way or 3 way switch or dimming control, 350 watt LED lighting load (minimum 9 watt)
- Complimentary key caps provided to suit most branded switch plates
- Complies to AS/NZS 60669.2, easy to retrofit, dim and switch with ease, with no messy additional wiring circuits required.
- Switch and dimming control is achieved only in conjunction with PIXIE (master) switch or dimmer. All devices must be paired once installed, for functionality.
- Fully compatible with the PIXIE app and PIXIE PLUS app, so with the inclusion of the SAL Gateway and the internet, you can control your PIXIE devices from anywhere in the world.









Technical Specification


Product	Model No.	Input Voltage (V/AC)	Body Colour	Dim (mm)
	S2W/BTAS	240	WHITE	42(L) x 24(W) x 24(H)

Due to continued product and technology enhancements, data sourced from sal.net.au shall not form part of any contract and or technical performance guarantee unless expressly confirmed in writing by SAL at the time of order. Products are sold in accordance with SAL Terms and Conditions of sale and all images shown are for illustration purposes only and may vary from the actual colour or finish. Unless specifically stated, all IP ratings nominated for Interior products are from "below the ceiling".





Dimensions



Case Issue	Suggestions		
The LED indicator of \$2W/BTAS doesn't light up when pressing the button	Please check the wiring and ensure the wiring is correct Check the connected load and ensure the load is within the power rating Press the button of connected PIXIE dimmer or switch, ensure it is functioning		
The LED indicator of \$2W/BTAS doesn't flash after quickly pressing the button 4 times	Please check the wiring and ensure the wiring is correct Check the connected load and ensure the load is within the power rating Press the button of connected POIG dimmer or witch, ensure it is functioning Ensure the POIG dimmer or witch is at OFF state (the light is off)		
The LED indicator of \$2W/8TAS flashes after quickly pressing the button 4 times, but it doesn't pair in the end	- Esses both the PIXE dimmer or switch and the PIXE Mulliway Control are in the policy made. - Enser use the SZWJETAS within wreless signal coverage of PIXE dimmer or switch within 15 meters in open space, may require closer promptly depending on the instalation environment! - If you pair in the App will the phone as this is recommended.		
The LED indicator of \$2W/BTAS shows it's paired successfully, but it doesn't do multiway control	Ensure the SZW/BTAS is within wireless signal coverage of the PIXE dimmer or swith (within 15 meters in open space, may require closer proximity depending on install environment) If SZW/BTAS has to be beyond within the state of the SZW/BTAS has to be beyond within the state of the SZW/BTAS has to be beyond when the state of the SZW/BTAS has to be beyond when the same state of the SZW/BTAS has to be beyond when the same state of the SZW/BTAS has to be beyond the same state of the SZW/BTAS has to be same state of the		



THE SFI SYSTEM ELIMINATES LED FLICKERING.

SIMPLY MATCH THE ECOGEM SFI DOWNLIGHT WITH THIS SDD400SFI DIMMER







DIM with FLICKER CONTROL

For related products please scan me



NSW/ACT: 02 9723 3099 QLD: 07 3879 5999 VIC/TAS/SA/NT: 03 9532 3168 WA: 08 9248 7458

