


56000 SILVER STRENGTH TRAINING SERIES FUNCTIONAL CABLE CROSSOVER OWNER'S MANUAL



BEFORE YOU START

PLEASE READ THIS INSTRUCTION MANUAL BEFORE YOU BEGIN ASSEMBLY. Great care has been taken to design these instructions and following them will help you with quicker assembly and minimize the risk of injury.

It is important that you keep these instructions for future reference.

This list is not exhaustive - You are responsible for your own safety!

- · Assemble the product on a level surface
- · You will need at least one person to help you assemble this unit.
- · Always use the product on a level surface, ensure that the product is stable before use.
- · Always ensure that the equipment has adequate space on each side and front (the back can be near to a wall).
- · Replace defective components immediately, and/or keep the equipment out of use until it is repaired.
- Use only the adjustment settings as described in the instructions. Always use the correct adjustment pin and/or locking devices.
- Always check that any pins / fixings are tight and secure before use and / or after adjustment.
- · Never leave any adjustment devices projecting from the product.
- · Always consult your doctor before undertaking any exercise program.
- · Always wear suitable clothing and footwear e.g. tracksuit / shorts / training shoes
- · Remove all personal jewelry before exercising.
- · Ensure you warm-up well before using the equipment as this will help to prevent muscle strain.
- · Injuries to health may result from incorrect or excessive training.
- · We recommend that you do not lift weights alone. There should be somebody there to assist you.
- Never use the equipment in any other manner other than the ways explained in these instructions and/or any wall-chart supplied.
- Parents and others in charge of children should be aware of their responsibility, because the natural play instinct and
 the fondness of experimenting of children can lead to situations and behavior for which the training equipment is not
 intended.
- If children are allowed to use the equipment, their mental and physical development and above all their temperament should be taken into account. They should be controlled and instructed in the correct use of the equipment.
- The equipment is under no circumstances suitable as a children's toy.
- · Children should not be allowed on, or around the equipment especially when it is not in use.
- Due to our continuous policy of product development, York Barbell reserves the right to change specifications without notice.

CAUTION! The instructions must be followed carefully in the assembly, use and maintenance of your equipment. The warranty does not cover damage due to negligence of the assembly, adjustment and maintenance instructions described herein.

THIS PRODUCT IS NOT SUITABLE FOR THERAPEUTIC PURPOSES.

TOOLS AND CONSUMABLES


- -- 1 x 1/4" Socket Head Wrench / Spanner
- -- 1 x 2.5mm Socket Head Wrench / Spanner
- -- 1 x 4mm Socket Head Wrench / Spanner
- -- 1 x 5mm Socket Head Wrench / Spanner
- -- 1 x 6mm Socket Head Wrench / Spanner
- -- 1 x 8mm Socket Head Wrench / Spanner
- -- 1 x 10mm Socket Head Wrench / Spanner
- -- 1 Philips Screwdriver

^{*} Pliers should not be used!

CUSTOMER SUPPORT

Should you require any assistance regarding this product please gather the following information and then contact us using the details below:

- · Serial No. This can be found on the sticker below, located as indicated.
- · Original purchase date
- · Place of purchase
- · Information about the place and conditions of use
- · Precise description of the issue / defect



IMPORTANT!! - Please retain your sales receipt, York Barbell Customer Care may request proof of purchase to validate eligibility for warranty service. Warranty cover starts from the date shown on the proof of purchase.

CARE & MAINTENANCE

- · Always place the equipment in a dry environment.
- · Use a warm, damp cloth to keep the product clean.
- The safety level of the equipment can be maintained only if it is regularly examined for damage and wear at the start of every use. This includes any nuts, bolts, moving parts, bushes etc.
- Always replace damaged / worn components with original parts from the manufacturer.

PREPARE YOUR WORK AREA - It is important you assemble the product in a clean and uncluttered space.

WORK WITH A FRIEND - We recommend you have someone assist you with the assembly as some of the components are quite heavy.

UNPACK THE CARTON - Remove all the parts and lay them out on the floor.

CHECK TO MAKE SURE YOU HAVE ALL PART, NUTS, BOLTS... ETC, BEFORE YOU START ASSEMBLY.

IF YOU ARE MISSING ANY PARTS AND THE BOX WAS UN-OPENED WHEN YOU LEFT THE STORE, PLEASE CONTACT YORK CUSTOMER SERVICE via http://yorkbarbell.com.


PRE-ASSEMBLY CHECK LIST

x 2PCS


Carton 1/1



22 10LB Counter Weight Stack Set




1 Left Upright Frame x1PC



2 Right Upright Frame x1PC



4 Lower Frame Connector x 1PC



3 Frame Connector with Pull Up Station x1PC



18 Ankle Strap x1PC




19 Tricep Rope x1PC




x4PCS 37 Rubber Foot-175x125x11mm



69 Single Grip
Attachment x2PCS



17 Short Bar x1PC



99 Long Bar x1PC





12 Middle Frame Connector x 1PC


CHECK	ITEM	QTY	DESCRIPTION
	1	1	Left Upright Frame
	2	1	Right Upright Frame
	3	1	Frame Connector with Pull Up Station
	4	1	Lower Frame Connector
	6	2	Rotary Frame
	7	2	Roller Hanger
	8	1	Left Adjusting Pipe
	9	1	Right Adjusting Pipe
	10	4	Guide Rod -20x1726mm
	11	2	Guide Rod Fixing Plate
	12	1	Middle Frame Connector
	13	4	Mounting Pole
	14	4	Ringer
	15	2	Shield
	16	2	298-3/7"(7580MM) 4.8 Cable Set
	17	1	Short Bar
	18	1	Ankle Strap
	19	1	Tricep Rope
			10LB Weight Stack
			•
		2	17 Holes Shaft
	24	2	Select Pin
	25	2	Spring Pin-10x45mm
	26	5	Hoist Hook-7x66mm
	27	4	Rolling Bearing -32x12x10mm
	31	2	Pulley-114x25.8mm
	32	14	Pulley-89x25.8mm
	33	4	Hollow Pipe Sleeve
	34	8	Rod End Cover
	35	2	Handle Grip-31.5x24x490mm
	36	4	Elliptical Tube Stopper -PT50x100x2mm
	37	4	Rubber Foot-175x125x11mm
	38	4	Rubber Bumper-62x20x26mm
	39	2	Rubber Bumper-38x33x15mm
	40	2	Plug-12.5x11.2x20mm
		4	Blind Nuts-M8
		2	Socket Cap Screw-M10x65mm
		2	Socket Cap Screw-M10x55mm
		2	Hex Nut-M12
	45	4	Umbrella Head Hexagon Socket Screw-M10x45mm


CHECK	<u>ITEM</u>	QTY	DESCRIPTION
	46	22	Socket Cap Screw-M10x25mm
	47	4	Umbrella Head Hexagon Socket Screw-M8x25mm
	48	2	Socket Cap Screw-M12x90mm
	49	14	Umbrella Head Hexagon Socket Screw-M10x50mm
	50	2	Umbrella Head Hexagon Socket Screw-M8x20mm
	52	40	Cross Recessed Pan Head Tapping Screw-ST4.2x16mm
	53	4	Flat Washer-24x13x2.5mm
	54	66	Flat Washer-20x10.5x2mm
	55	4	Big Washer-24x8.4x2mm
	56	40	Big Washer-15x5.3x1.2mm
	57	22	Spring Washer-M10
	58	8	Spring Washer-M8
	59	22	Nylon Insert Lock Nut-M10
	60	2	Nylon Insert Lock Nut-M12
		20	L Shape Plate
		2	
		2	Single Grip Attachment
		2	Rings Components
		2	Hook Cover
		2	Aluminum End Cover-38x6.5x13mm
	74	2	Aluminum Ring-32x23x14.5mm
	75	2	Aluminum Baffle Ring-35x26x13mm
	76	2	Plastic Ring-30x26x4.5mm
	77	2	Socket Cap Screw-M6x25mm
		2	Spring Washer-M6
	79	4	Inner Hexagon End Set Screw-M5x5mm
	80	4	Reinforcing Regula-16x9x1560mm
		4	Countersunk Head Pull mandrel Rivet-5x12mm
		2	
		1	Right Sliding Frame
	•	1	Left Sliding Frame
		2	Select Adjusting Frame
		2	Adjusting Bar
		2	Aluminum End Cover-32x6.5x12mm
	89	2	Spring-1.4x12.5x38mm
	90	2	Handle Grip Cover-31.5x24x490mm
	91	2	Handle Grip Cover-18x12x100mm

CHECK ITEM QTY DESCRIPTION							
	92	2	Roller Link 08A				
	93	2	Countersunk Head Hexagon Screw-M6x20mm				
	94	2	Reed Nut-M6x20.8x10mm				
	95	2	Elliptical Pipe Plug-PT50x100x3mm				
	96	8	Cross Recess Pan Head Screw-M4x10mm				
	97	8	Spring Washer-M4				
	98	8	Plain Washer-9x4.3x0.8mm				
	99	1	Long Bar				
	100	1	York Nameplate				
	101	1	Warning Lable				
	102	1	Warranty Card				
	103	1	Serial # Sticker				
	104	1	Hardware Card				
	105	1	Assembly Instruction				












http://yorkbarbell.com

56000



http://yorkbarbell.com






ASSEMBLY INSTRUCTION


STEP 1

- 4 Lower Frame Connector x 1PC
- 12 Middle Frame Connector x 1PC
- 37 Rubber Foot-175x125x11mm x 4PCS
- 46 Socket Cap Screw-M10x25mm x 16PCS
- 54 Flat Washer-20x10.5x2mm x 16PCS O
- 57 Spring Washer-M10 x 16PCS ①
- 1 (1+6+8+15+31+32+84)Pre-Assembly x 1PC
- 2 (1+6+9+15+31+32+83)Pre-Assembly x 1PC



STEP 2

- 46 Socket Cap Screw-M10x25mm x 6PCS
- 54 Flat Washer-20x10.5x2mm x 6PCS ©
- 57 Spring Washer-M10 x 6PCS
- 2 (3+35+73+74+75+76)Pre-Assembly x 1PC




56000

15

ASSEMBLY INSTRUCTION


STEP 3

- 7 Roller Hanger x 2PCS
- 10 Guide Rod-20x1726mm x 4PCS
- 11 Guide Rod Fixing Plate x 2PCS
- 24 Select Pin x 2PCS
- 34 Rod End Cover x 8PCS
- 38 Rubber Bumper-62x20x26mm x 4PCS
- 47 Umbrella Head Hexagon Socket Screw -M8x25mm (Pre-Assembly) x 4PCS
- 55 Big Washer-24x8.4x2mm (Pre-Assembly) x 4PCS (O)
- 58 Spring Washer-M8 (Pre-Assembly) x 4PCS
- 22 (22+23+25)Pre-Assembly x 2PCS



STEP 4

- 52 Cross Recessed Pan Head Tapping Screw-ST4.2x16mm (Pre-Assembly) x 20PCS
- 56 Big Washer-15x5.3x1.2mm (Pre-Assembly) x 20PCS (O)
- 66 (66+80)Pre-Assembly x 2PCS



ASSEMBLY INSTRUCTION

STEP 5


69 Single Grip Attachment x 2PCS

12 (12+26)Pre-Assembly x1PC

17 (17+26)Pre-Assembly x1PC

18 (18+26)Pre-Assembly x1PC

19 (19+26)Pre-Assembly x1PC



Please visit us at our website for more products and information.

