

LAWN & GARDEN ACCESSORY KIT

P/N 16386



800-222-6199 • 949-768-3333 • Fax 949-768-3336 www.TheCarlsonCompany.com


WARNING: READ INSTRUCTIONS BEFORE USE

The Lawn & Garden accessory kit is design to simplify ordinary maintenance of small engines, chain saws, and weed eaters. It can be attached to any Handy Lift table or the Handy Multi-Lift. The holders are not designed for testing of equipment while being held.

WARNING: Do not operate equipment while it is in the kit holder.


Basic Instructions:


- Attach base mount to the end of lift table as shown or to the inside cutout section of the Handy Multi-Lift. Make sure that the base mount is secure.
- Insert the appropriate accessory kit into the base mount and secure by tightening the knob on the post of the base mount.



Small Engine Kit -


Attach the engine by inserting the shaft into the holder. The holder will accommodate shaft sizes up to1" in diameter. Clamp the shaft by tightening the knob. The clamp is designed in a way that does not damage the shaft in any way.








LAWN & GARDEN ACCESSORY KIT





Chain Saw Kit - Lay the chain saw on the support pad with the blade positioned between the clamp supports. The support pad can be adjusted to accommodate different lengths of chain saws. Use the clamp lever to secure the chain saw blade. Adjust the screw behind the blade to get enough pressure to hold the blade. Secure the chain saw base to the support pad with tie downs using the holes in the support pad.





Weed Eater Kit - Attach the weed eater in the holder as shown and tighten the knob. It is best if the weed eater is attached somewhere near its balance point. The holder can be pivoted up and down by loosening the 3/8-16 socket head cap screw and the #8-32 socket head set screw with cup point. The holder can be rotated by loosening the knob.

