



# Toronto

LED Floor Light

User Guide

Read all instructions prior to using your new product.

## ASSEMBLY INSTRUCTIONS

- Slide light head onto base connector. NOTE: To tamper-proof the light head, install the optional set screw using the included allen wrench. Do not over tighten.

## USING YOUR LUX TORONTO LAMP

- Use only with the included 24V 0.625A power supply.
- Turn on the light by pressing gently on the power switch on the end of the light bar.
- Press the power switch again to cycle through the three brightness levels (420, 200, 20 lumens).
- The Toronto's silicone flexible neck is adjustable, however the aluminum light bar is not.

## SAFETY INFORMATION:

- The flexible external power supply cable cannot be replaced; if the cable is damaged the entire power supply must be replaced.
- For indoor use only; do not use outdoors.
- Switch off the light before disconnecting the power supply.
- Do not look directly at the LEDs when they are illuminated.

## CUSTOMER SERVICE:

For questions and assistance please contact us at:  
800.922.3233 • [customerservice@mightybright.com](mailto:customerservice@mightybright.com)





Visit us at:  
[www.luxledlights.com](http://www.luxledlights.com)