



ORDER	ITEM NUMBER	PART NAME	QTY	ORDER	ITEM NUMBER	PART NAME	QTY	
	1	12-734	Handle (Right Hand)	1	14	12-713	Spring Stop Plate	1
	2	12-735	Handle (Left Hand)	1	15	12-714	Main Spring	1
	3	12-702	Trigger Assembly	1	16	12-715	Gulde Pin	3
	4	12-733	Magazine Assembly	1	17	12-716	Adjusting Knob	1
	5	12-704	Follower Assembly	1	18	12-717	Square Nut	1
	6	12-737	Channel	1	19	12-718	Washer	1
	7	12-738	Push Plate	1	20	12-719	Follower Spring	1
	8	12-707	Bumper	1	21	12-720	Cap	1
	9	12-708	Stop Bar	1	22	12-721	Trigger Spring	1
	10	12-709	Hammer	1	23	12-722	Pan Head Screw	2
	11	12-710	Pawl	1	24	12-723	Plastite Screw	3
	12	12-711	Pawl Pin	1	25	12-731	Magazine Screw	1
	13	12-712	Torsion Spring	1	26	12-725	Magazine Nut	1