

# 6" RING LIGHT MULTIPOD



USER  
MANUAL

## PRODUCT INTRODUCTION PARTS



6" Ring Light Multipod



Wireless Remote Shutter  
(attached to Multipod)



USB Charging Cable

## HOW TO SET UP



### STEP 1:

Loosen locking knob by turning counter-clockwise until moderately loose.

## HOW TO SET UP



### STEP 2:

Flip up Ring Light all the way up. Tighten locking knob by turning in clockwise direction to set Ring Light position.

## HOW TO SET UP



### STEP 3:

Pull apart Tripod legs and extend center column until desired height is achieved. Extends up to 32".

**IMPORTANT!**  
For Tripod to stand balanced on legs the center column base must not touch ground surface. Pull out center column until base hovers above ground surface.

## HOW TO SET UP



### STEP 4:

Pull out upper and lower clamps from rotating phone holder. Lift up spring loaded upper clamp and insert phone.

Phone Clip opens up to 2.8" to fit most phones

ROTATES

## HOW TO SET UP (Selfie Stick)



EXTENDS UP TO 28"

### STEP 1:

Make sure Tripod legs are in closed position and locked in place. Extend center column extension to desired length. Press shutter button to record video or take a photo. Look at pairing instruction page.

## HOW TO USE (Turn ON Ring Light)

### WHITE



3 Brightness Levels

### NATURAL



3 Brightness Levels

### WARM



3 Brightness Levels

### STEP 1:

Press and hold the ON/OFF button located on the underside of Ring Light until light turns on. Click repeatedly to switch between Warm/Natural/White Light modes. Press and hold to turn power OFF.



ON/OFF  
Button

## HOW TO USE (Charging the Ring Light)



### IMPORTANT!

Do not remove rechargeable internal battery. May cause damage or injury.

### STEP 1:

Connect the smaller tip end to the underside of the Ring Light. Then connect bigger USB tip to a USB port (Computer/Laptop/Wall Charger/ Power Bank, etc.) to begin charging. Illuminated Red color light indicates charging is in progress. When charging is complete Red light will turn off.

## HOW TO USE (Wireless Remote)



SLIDE UP  
TO REMOVE  
REMOTE

### STEP 1 (Wireless Pairing):

Press and hold camera button for 3 seconds to turn on. The indicator light flashes for 4 seconds to enter pairing state, the Blue indicator light of the pairing state flashes. Go to your phones Bluetooth® settings(turn Bluetooth® ON) and search for "Bower RL", press it and the Blue indicator light will turn off after pairing is successful Begin capturing photos and videos!

**NOTE:**  
Removable top lid for battery replacement

## HOW TO USE (Wireless Remote Continued)

- No Pairing:** After booting, in the state of no pairing connection, it will automatically shut down after 5 min. of no operation.
- Pairing:** After turning on the phone, when 6" Ring Light Multipod is connected to the phone, it will enter the dormant state if there is no operation for 10min., and it will automatically shut down after another 10min.
- Power Off:** In power on and sleep mode, press and hold the camera button for 3 seconds to power off, the indicator light flashes and goes out.

### FEATURES:

- 6" Ring Light: Choose from three different lighting modes: Warm, Natural, White and three different brightness settings
- Extendable Tripod up to 32" + Selfie Stick allow for versatile use
- Includes detachable Wireless Remote for your convenience
- No batteries required: rechargeable internal battery with USB Charging Cable
- Great for travel, folds to compact size

### SPECIFICATION:

Power Supply:	USB Power Supply
Input power:	5W±10%
Color Temperature:	3000 k / 4000 k / 6500 k
Luminous flux:	140 LM
CRI:	> 85
Stroboscopic:	No
Dimming:	3 Level Dimming
LED bead type:	0.2W/2835
Lamp Beads:	56
Battery Capacity:	1200mAh
Product size:	6.7" x 6.1" x 3"

Compatible with Android® 4.2.2 and above/iPhone iOS® 5.0 and above. Android devices only: If you have changed your "Volume Keys Function" under camera options, make sure to change it back to default, or "take pictures" for 6" Ring Light Multipod to work properly.

### Disclaimer:

This manual should be kept for future reference and maintenance purposes only. Be sure to review this manual and become familiar with its features before using this product. Please make sure to never change the light bulb while plugged into an outlet or other power source. Do not open or change wiring in anyway. Keep this product away from children. Clean this product often with a soft, dry cloth. This product shall ONLY be used with rated voltage and frequency. Do not try and alter power supply or adjust voltage. Avoid unplugging the power by pulling the power cord and do not touch the power cord with wet hands. Never attempt to insert any metal objects into the cooling holes of illuminators. Avoid moving the illuminator by pulling the power cable. Stop using this product if the unit is damaged, especially the power cord. Do not use in the rain, bath, or near water source. Please be aware that improper use or inappropriate repair can lead to fire or electrocution. Indoors use only. Please send back to Bower or contact customer service for issues regarding maintenance or repair. Make sure everything is secure before proceeding. Make sure the product is intact and that there are no missing parts. All photos and illustrations are for instruction purposes only.

### LIMITED One (1) Year Limited Warranty

**S. Bower Inc.™ One (1) Year Limited Warranty: This warranty gives you specific legal rights and you may have other rights which vary from state to state.**

The S. Bower Inc.™ Limited Warranty is a voluntary manufacturer's warranty provided to the consumer. This warranty provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. S. Bower Inc.™ One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty terms and conditions shall not apply to consumer law claims, contact your local consumer organization. Please note: All claims made under the S. Bower Inc.™ One-Year Limited Warranty will be governed by the terms set out in this warranty document.

S. Bower Inc.™ warrants to the product owner that this product will be free against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase when used in accordance with S. Bower Inc.™'s user manual. Under this warranty, you will be able to send your claims and defective product to S. Bower Inc.™, via freight prepaid, along with proof of purchase, and will be repaired or replaced, based on S. Bower Inc.™'s sole discretion. Repair and/or replacement may be made with new or refurbished product components at S. Bower Inc.™'s sole discretion. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than S. Bower Inc.™ personnel. A defective product meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways: The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges. Proof of purchase may be required. Please check with the retailer for its specific return policy regarding time limits for returns or exchanges. The second option is to send the product (prepaid freight) to S. Bower Inc.™ corporate offices located at S. Bower Inc., 38-09 43rd Avenue 1st Floor Long Island City, NY 11101 for repair or replacement at S. Bower Inc.™'s option. Proof of purchase is required. Include name, return address, and issues that you are experiencing with S. Bower Inc.™ products. All other guarantees, express or implied, are hereby disclaimed.

**This warranty does not apply to products sold in countries sold out of the United States.**