

HOW TO USE:

Charging the device:

Use provided USB-C charging cable and connect USB-C end into device and USB-A end into any USB port such as on a computer USB port, wall charger USB port, portable power bank USB port.

When this product is charging, the red light is steadily on; When fully charged, the red light goes out. When the red light blinks the battery is empty and needs to be recharged.

Mounting on to a camera:

Simply slide out light from Clip-mount and insert into camera hot-shoe mount.





IN THE BOX:



HOW TO USE:

Mounting on to a monitor, phone, tablet:

Push in Clip-on Mount Button to open clip and attach to your device. Clip opens up to 0.57 in. (max).



Specifications:

- » Power: 4W
- » Input: Type-C interface 5V/1.0A
- » Power supply: Built-in 3.7V Lithium Battery
- » Lithium battery capacity: 500mAh
- » LED light beads aty: 40
- » Light beads type: 5050 Lamp Bead
- » Luminous angle: 120°
- » Protection level IP: IP20
- » Continuous lighting time: Up to 40 minutes
- » Charging time: About 2 hrs
- » Color temperature: 3000-7000k
- » 3 White Light Modes, 6 RGB Colors, 6 Special Effect Modes
- » Size: 3.6 in.(width) x 5 in.(height) x 1.9 in.(depth)

PRODUCT PARTS:



- 1) Smooth Light
- 2) Diamond Crystal Light
- 3) Clip-on Mount
- 4) Clip-on Mount Button
- 5) USB-C Charging Port
- 6) RGB Mode Button
- 7) White Light Mode Button
- 8) Cold Shoe Mount
- 9) Camera Hole

LIMITED One (1) Year Limited Warranty

S. Bower Inc.TM One (1) Year Limited Warranty: This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The S. Bower Inc.™ Limited Warranty is a voluntary manufacturer's warranty provided to the consumer. This warranty provides rights separate to rights provided by consumer low, including but not limited to those relating to non-conforming goods. S. Bower Inc.™ One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty local consumer organization. Please note: All claims made under the S. Bower Inc.™ One-Year Limited Warranty will be governed by the terms set out in this warranty document. S. Bower Inc.™ or one-Year Limited Warranty will be governed by the terms set out in this warranty document. S. Bower Inc.™ or one-Year Limited Warranty will be governed by the terms set out in this warranty document. S. Bower Inc.™ or one-Year Limited Warranty will be governed by the terms set out in this warranty document. S. Bower Inc.™ or of the date of original retail purchase when used in accordance with S. Bower Inc.™ 's user manual. Under this warranty, you will be able to send your claims and defective product to S. Bower Inc.™ or included a product components at S. Bower Inc.™ sole discretion. Repair and/or replacement may be made with new or refurbished product components at S. Bower Inc.™ sole discretion. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than S. Bower Inc.™ personnel. A defective product a meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways: The first, which will result

This warranty does not apply to products sold in countries sold out of the United States.

HOW TO USE:

Turn on/off light:

Press and hold the W button (long press) to turn on the device when the light is off. When the light is on, press and hold the W button (long press) to shut it off; This product has the function of lamp memory. Every time the lig is turned on, it will open to the same state when the light was turned off.

Switching between RGB and White Light Mode:

When the RGB mode is on(R button), press W button (short press) to switch to White light mode. Once in White Light Mode, press W button repeatedly(short press) to change White Light Modes (warm, natural, white).

In White Light Mode, press the R button (short press) to switch to RGB Mode; When the RGB mode is on, press the R button repeatedly (short press) to change between RGB colors and Special Effects.

Switching between front/back light & dual lighting:

The device has the ability to have either front or back light powered on, as well as both sides powered on simultaneously.

When the light is powered on, press and hold the R button (long press) to switch between (front - back - double side). Repeat this step until desired choice appears.

©2023 S. Bower, Inc. All rights reserved.

All brand names and trademarks belong to their respective owners $\,$

S. Bower, Inc. LIC, NY 11101 www.BowerUSA.com