

GRAPPLING VLOGPOD

WITH BENDABLE ARMS AND LEGS



USER
MANUAL

IN THE BOX:

- DSLR/Action Cam 1/4" Universal Screw Mount
 - Foldable Phone Holder
 - Quick Lock Knob (for DSLR/Action Cam)
 - 360° Rotating Ball Head
 - 1/4" Screw Thread (2) for Removable Arms
 - 360° Ball Head Locking Knob
 - Removable feet for accessory attachment
- 
- ACTION CAM ADAPTER**
- 
- REMOVABLE ARMS (2)**
- 
- VLOGPOD**

INSTALLATION

Step 1

Spread apart Vlogpod legs and set on top of a flat surface. Pull out Phone Holder clamp and lift up Phone Holder.



NOTE: Phone Holder Clamp must be in opened first (as shown above) to open the Phone Holder.

INSTALLATION

Step 2

Lift up spring loaded clamp, and insert smartphone.



Step 3

Insert Removable Arms into Vlogpod (optional). Screw in until tight. Do not over tighten, should feel firmly screwed in.


NOTE: Removable feet can be unscrewed for additional accessory attachment.



INSTALLATION

Step 4

Screw in accessories (LED Light/Mic sold separately) into arms.



INSTALLATION (DSLR Camera/Compact Camera)

Make sure the Foldable Phone Holder is in closed position (see below diagram). Tighten lock knob firmly, do not over tighten. Position DSLR camera above screw and turn Quick Lock Knob to screw in.




INSTALLATION (Acion Camera)

Affix Your action cam in to the Action Cam Adapter. Make sure Phone Holder is in closed position (see below diagram). Tighten lock knob firmly, do not over tighten. Position the mounted action camera above screw and turn Quick Lock Knob to screw in.



HOW TO USE (Bending/Grappling)

Vlogpod features bendable arms and legs. Simply bend to the desired positioning wanted. Grapples on to most tube shaped objects, and more (securely attach).



HOW TO USE (Hand-held Stabilizer)

Keep legs in closed position and hold firmly. Can be used with or without Removable Arms. Works with smartphones, small DSLR's, compact cameras, and action cameras.



FEATURES:

- Bendable arms/legs with high quality 360° Rotating Ball Head and compact design.
- Bends and wraps around objects and functions as a hand stabilizer.
- Bendable arms with 1/4" universal screw thread allows for attachment of a multitude of video/photo accessories.
- Great for vlogging, live videos, video chats, social media, live streaming, and more.
- Compatible with smartphones, action cameras, compact cameras, and small DSLR cameras.

SPECIFICATION:

Weight:	1.2 lb (555 g)
Max Load Capacity:	5.5 lb (2.5 kg)
Height (open position):	14"
Height (closed position):	13"
Width (open position):	10"
Width (closed position):	3"
Foot Diameter:	.75"
Phone Holder (max opening):	3.2"

Disclaimer:

This manual should be kept for future reference and maintenance purposes only. Be sure to review this manual and become familiar with its features before using this product. Please make sure to never change the light bulb while plugged into an outlet or other power source. Do not open or change wiring in anyway. Keep this product away from children. Clean this product often with a soft, dry cloth. This product shall ONLY be used with rated voltage and frequency. Do not try and alter power supply or adjust voltage. Avoid unplugging the power by pulling the power cord and do not touch the power cord with wet hands. Never attempt to insert any metal objects into the cooling holes of illuminators. Avoid moving the illuminator by pulling the power cable. Stop using this product if the unit is damaged, especially the power cord. Do not use in the rain, bath, or near water source. Please be aware that improper use or inappropriate repair can lead to fire or electrocution. Indoors use only. Please send back to Bower or contact customer service for issues regarding maintenance or repair. Make sure everything is secure before proceeding. Make sure the product is intact and that there are no missing parts. All photos and illustrations are for instruction purposes only.

LIMITED One (1) Year Limited Warranty

S. Bower Inc.™ One (1) Year Limited Warranty: This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The S. Bower Inc.™ Limited Warranty is a voluntary manufacturer's warranty provided to the consumer. This warranty provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. S. Bower Inc.™ One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty terms and conditions shall not apply to consumer law claims, contact your local consumer organization.

Please note: All claims made under the S. Bower Inc.™ One-Year Limited Warranty will be governed by the terms set out in this warranty document.

S. Bower Inc.™ warrants to the product owner that this product will be free against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase when used in accordance with S. Bower Inc.™'s user manual. Under this warranty, you will be able to send your claims and defective product to S. Bower Inc.™, via freight prepaid, along with proof of purchase, and will be repaired or replaced, based on S. Bower Inc.™ sole discretion. Repair and/or replacement may be made with new or refurbished product components at S. Bower Inc.™ sole discretion. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than S. Bower Inc.™ personnel. A defective product meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways: The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges. Proof of purchase may be required. Please check with the retailer for its specific return policy regarding time limits for returns or exchanges. The second option is to send the product (prepaid freight) to S. Bower Inc.™ corporate offices located at S. Bower Inc., 38-09 43rd Avenue, Floor Long Island City, NY 11101 for repair or replacement at S. Bower Inc.™'s option. Proof of purchase is required. Include name, return address, and issues that you are experiencing with S. Bower Inc.™ products. All other guarantees, express or implied, are hereby disclaimed.

This warranty does not cover products sold outside of the United States.