

Covers, by Kettal Studio

CASA
DESIGN
GROUP

Covers

Water-resistant cover
100% Polyester

Kettal covers resist water, oil and dirt, functioning to protect the furniture. They are not recommended as a permanent cover for cushions, as moisture may collect and lead to the formation of mold. Furniture and cushions should be thoroughly dry before using the covers. In order to increase the circulation of air and avoid the formation of condensation, the covers are not made to floor length. Never pack or fold covers that have become wet; instead, let them dry in a well-ventilated place. Use a soft cloth and warm water to clean the covers, using a gentle upholstery cleaner if necessary. Rinse with clear water. Solvents are not suitable for cleaning the covers as these are aggressive to the surface and may cause damage and discoloration.



Thermoweld



Elastic band with a hook



Adjustable rubber band



Air vent

