


Instruction Manual

JuiceBox Pro 20100mAh
60W USB-C PD Wireless External Battery




JuiceBox Pro 20100mAh External Battery



User Manual

Thank you for purchasing our product. To ensure optimal performance and safety, please read the following instructions carefully before operating this product. Please keep this manual for future reference.



Product Part	Operation
1 Power Button	Click on the power button to turn on the power bank.
2 Wireless Charging Panel	Make sure the device is aligned with the center of the power bank. Make sure your device is compatible with wireless charging. Wireless Charging Output: DC 5V/1A(max)
3 Power Indicator	Check remaining power.
4 USB C PD Port	Any connected devices will be automatically recognized. Input/Output: DC 5-20V/3A(max)
5 Dual USB Output	Output: DC 5V/3A(max)

Product Features

- High Capacity of 20100mAh.
- 45W USB C PD Charging: Charge your USB-C mobile phones and laptops at high-speed with max 45W Power Delivery charging.
- Wireless Charging Support all Qi-enabled phones for inductive charging at ultimately astonished speed.
- Smart LED Display shows remaining power.

Specifications

- Battery Type: Li-Ion battery
 - Capacity: 20100 mAh/72.96Wh
 - Input: DC 5-20V/3A(MAX)
 - Output:
 - ⚡ USB C PD: DC 5-20V/3A(MAX)
 - ⚡ USB A: 5V/3A(MAX)
 - ⚡ Wireless Output: 5V/1A(MAX)
- Weight: 465g(16.4 ounces)
Product Dimension: 6.25 x 3.26 x 1.18 in

How to Use the External Battery?

1. Charge your Devices: Press the power button to turn on the battery and charge your devices. For USB C charging, any connected devices will be automatically recognized.
2. Charging your Devices Wirelessly: Put the device on center of the wireless charging panel.

How to Charge the External Battery?

1. To ensure optimal performance and user safety, only use an official cellphone charger or ZeroLemon authorized charger when charging.
2. It takes 2-8 hours to fully charge the external battery based on the charging output of the charger.
3. The digit will flash when the external battery is being charged. It will show 100% when the external battery is fully charged.

How to Charge your Devices?

1. Press the power button to begin charging. For USB C charging, any connected devices will be automatically recognized.
2. Only use the supplied charging cable or your phone's charging cable when charging.
3. Disconnect your phone/tablet from the external battery when charging is completed.

Caution

1. Keep the external battery away from high temperatures.
2. Do not disassemble the external battery.
3. Recharge the battery at least once every month to maintain optimal performance.
4. For optimal use and user safety, use only an official phone charger or ZeroLemon charger to recharge.
5. Keep the battery away from metallic objects.
6. Do not crush the battery.

Package Contents

- 1 x 20100mAh External Battery
- 1 x Instruction Manual

Warranty and 100% ZeroLemon Guarantee

This product is covered by our 12-Month ZeroLemon Warranty.

Customer satisfaction is always our #1 priority. If your product is not working as it should or if you would like to return it to us for any reason, please let us know by contacting us at info@zerolemon.com

We promise to deliver only the best quality products and offer 100% customer satisfaction.

Subscribe to us
for more deals and news!



Sales Inquiry: sales@zerolemon.com
Designed by ZeroLemon, LLC in USA
Made in China

Copyright 2019 ZeroLemon, LLC All Rights Reserved.
All names, brands, logos, and/or trademarks used in this publication are property of their respective owners.

www.zerolemon.com